
# **GDM-FW9011**

# SERVICE MANUAL

# N.Hemisphere Model

Chassis No. SCC-L34C-A



G1W CHASSIS

## **SPECIFICATIONS**

CRT 0.23 - 0.27 mm aperture grille pitch

24 inches measured diagonally

90-degree deflection

FD Trinitron

Approx.  $482.1 \times 308.2 \text{ mm (w/h)}$ Viewable image size

 $(19 \times 12^{-1}/4 \text{ inches})$ 

22.5" viewing image

Resolution

Maximum (16:10) Horizontal: 2304 dots Vertical: 1440 lines

Maximum (4:3)

Horizontal: 2048 dots

Vertical: 1536 lines

Recommended (16:10)

Horizontal: 1920 dots Vertical: 1200 lines

Video signal

Input signal levels Analog RGB: 0.700 Vp-p

(positive), 75  $\Omega$ 

SYNC signal

H/V separate or composite sync:

TTL 2  $k\Omega$ , Polarity free Sync on Green: 0.3 Vp-p

(negative)

Standard image area

Approx.  $474 \times 296 \text{ mm (w/h)}$ 

 $(18^{3}/4 \times 11^{3}/4 \text{ inches})$ 

Approx.  $395 \times 296 \text{ mm (w/h)}$ 

 $(15^{5}/8 \times 11^{3}/4 \text{ inches})$ 

Approx.  $370 \times 296 \text{ mm (w/h)}$  $(14^{5/8} \times 11^{3/4} \text{ inches})$ 

Horizontal: 30 to 121 kHz Deflection frequency\* Vertical: 48 to 160 Hz

100 to 240 V, 50/60 Hz, 2.2 – 1.2 A AC input voltage/current

Approx. 170 W (with no USB devices Power consumption

connected)

Operating temperature 10°C to 40°C Dimensions

Approx. 571.5 × 500 ×

d)  $(22^{1/2} \times 19^{3/4} \times 20^{5/8} \text{ inches})$ Approx. 42 kg (92 lb 10 oz)

DDC1/DDC2B/DDC2Bi, GTF\*\* Plug and Play Supplied accessories · This operating instruction

\* Recommended horizontal and vertical timing condition

· Horizontal sync width duty should be more than 4.8% of total horizontal time or 0.8 µs, whichever is larger.

• Horizontal blanking width should be more than 2.3 µsec. Vertical blanking width should be more than 450 usec.

\*\* If the input signal is Generalized Timing Formula (GTF) compliant, the GTF feature of the monitor will automatically

provide an optimal image for the screen.


Design and specifications are subject to change without notice.

**COLOR GRAPHIC DISPLAY** 

# SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

- Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- 2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- 3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
- Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
- 6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
- Check the B+ and HV to see if they are specified values.
   Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
- Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC Leakage. Check leakage as described below.



# LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampers).

Leakage current can be measured by any one of three methods.

- A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- 2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- 3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate lowvoltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOMs that are suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)

### **WARNING!!**

NEVER TURN ON THE POWER IN A CONDITION IN WHICH THE DEGAUSS COIL HAS BEEN REMOVED.

SAFETY-RELATED COMPONENT WARNING!! COMPONENTS IDENTIFIED BY SHADING AND MARK 
ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL FOR SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL FOR SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

### **AVERTISSEMENT!!**

NE JAMAIS METTRE SOUS TENSION QUAND LA BOBINE DE DEMAGNETISATION EST ENLEVÉE.

# ATTENTION AUX COMPOSANTS RELATIFS À LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET UNE MARQUE A SONT CRITIQUES POUR LA SÉCURITÉ. NE LES REMPLACER QUE PAR UNE PIÈCE PORTANT LE NUMÉRO SPECIFIÉ. LES RÉGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIÉS DANS LE PRÉSENT MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNEMENT EST SUSPECTÉ.

## POWER SAVING FUNCTION


This monitor meets the power-saving guidelines set by VESA, ENERGY STAR, and NUTEK. If the monitor is connected to a computer or video graphics board that is DPMS (Display Power Management Signaling) compliant, the monitor will automatically reduce power consumption in three stages as shown below.

Power mode	Power consumption*	① (power) indicator
normal operation	≤ 170 W	green
1 standby	≤ 15 W	green and orange alternate
2 suspend (sleep)**	≤ 15 W	green and orange alternate
3 active off*** (deep sleep)**	≤ 1 W	orange
power off	0 W	off

- \* Figures reflect power consumption when no USB compatible peripherals are connected to the monitor.
- \*\* "Sleep" and "deep sleep" are power saving modes defined by the Environmental Protection Agency.
- \*\*\* When your computer enters power saving mode, the input signal is cut and NO INPUT SIGNAL appears on the screen before the monitor enters active off mode. After a few seconds, the monitor enters power saving mode.

# **DIAGNOSIS**

This monitor is equipped with a self-diagnosis function. If there is a problem with your monitor or computer(s), the screen will go blank and the ① (power) indicator will either light up green or flash orange. If the ① (power) indicator is lit in orange, the computer is in power saving mode. Try pressing any key on the keyboard or moving the mouse.



# ■ If the ① (power) indicator is green

- Disconnect any plugs from the video input 1 and 2 connectors, or turn off the connected computer(s).
- 2 Press the ① (power) button twice to turn the monitor off and then on.
- 3 Move the joystick to the right for 2 seconds before the monitor enters power saving mode.



If all four color bars appear (white, red, green, blue), the monitor is working properly. Reconnect the video input cables and check the condition of your computer(s).

If the color bars do not appear, there is a potential monitor failure. Inform your authorized Sony dealer of the monitor's condition.

# ■ If the ① (power) indicator is flashing orange

# Press the $\odot$ (power) button twice to turn the monitor off and then on.

If the  $\bigcirc$  (power) indicator lights up green, the monitor is working properly.

If the  $\bigcirc$  (power) indicator is still flashing, there is a potential monitor failure. Count the number of seconds between orange flashes of the  $\bigcirc$  (power) indicator and inform your authorized Sony dealer of the monitor's condition. Be sure to note the model name and serial number of your monitor. Also note the make and model of your computer and graphic board.

# **GDM-FW9011**

# TIMING SPECIFICATION

					PRIMARY				
MODE AT PRODUCTION	MODE 1	MODE 2	MODE 3	MODE 4	MODE 5	MODE 6	MODE 7	MODE 8	MODE 9
RESOLUTION (HXV)	640 X 480	720 X 400	1920 X 1080	1600 X 1024	1920 X 1200	2304 X 1440	1600 X 1024	1920 X 1080	1920 X 1080
CLOCK	25.175 MHz	28.322 MHz	172.798 MHz	198.832 MHz	282.744 MHz	383.863 MHz	170.447 MHz	216.023 MHz	216.023 MHz
— HORIZONTAL —									
H-FREQ	31.469 kHz	31.469 kHz	67.080 kHz	91.375 kHz	107.100 kHz	120.560 kHz	81.320 kHz	84.384 kHz	84.384 kHz
	usec	usec	usec	usec	usec	usec	usec	usec	usec
H. TOTAL	31.778	31.777	14.908	10.944	9.337	8.295	12.297	11.851	11.851
H. BLK	6.356	6.355	3.796	2.897	2.546	2.292	2.910	2.963	2.963
H. FP	0.636	0.636	0.694	0.563	0.538	0.458	0.188	0.222	0.222
H. SYNC	3.813	3.813	1.204	0.885	0.736	0.667	0.939	1.000	1.000
H. BP	1.907	1.907	1.898	1.448	1.273	1.167	1.784	1.741	1.741
H. ACTIV	25.422	25.422	11.111	8.047	6.791	6.002	9.387	8.888	8.888
— VERTICAL —									
V. FREQ(Hz)	59.940 Hz	70.087 Hz	60.000 Hz	85.000 Hz	85.000 Hz	80.000 Hz	76.000 Hz	72.000 Hz	72.000 Hz
	lines	lines	lines	lines	lines	lines	lines	lines	lines
V. TOTAL	525	449	1118	1075	1260	1507	1070	1172	1172
V. BLK	45	49	38	51	60	67	46	92	92
V. FP	10	12	1	1	1	1	3	3	3
V. SYNC	2	2	3	3	3	3	3	3	3
V. BP	33	35	34	47	56	63	40	86	86
V. ACTIV	480	400	1080	1024	1200	1440	1024	1080	1080
— SYNC —									
INT(G)	NO	NO	NO	NO	NO	NO	NO	NO	NO
EXT(H/V)/POLARITY	YES N/N	YES N/P	YES N/N						
EXT(CS)/POLARITY	NO	NO	NO	NO	NO	NO	NO	NO	NO
INT/NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT

# TABLE OF CONTENTS

Sec	<u>rtion</u>	<u>Title</u>	<u>Page</u>
1.	GEN	ERAL	1-1
2.	DISA	ASSEMBLY	
	2-1.	Cabinet Assy Removal	2-1
	2-2.	D Board Removal	
	2-3.	G Board Removal	2-2
	2-4.	A Board and I/O Terminal Board Assy	
		Removal	2-2
	2-5.	S Board Removal	2-3
	2-6.	N Board Removal	2-3
	2-7.	Service Position	2-4
	2-8.	Picture Tube Removal	2-4
	2-9.	Control Block Assy Removal	2-5
	2-10.	J Board Removal	2-6
	2-11.	US Board Removal	2-6
	2-12.	Harness Location	2-7
3.	SAF	ETY RELATED ADJUSTMENT	3-1
4.	ADJ	USTMENTS	4-1
5.	DIAC	GRAMS	
	5-1.	Block Diagrams	5-1
	5-2.	Frame Schematic Diagram	5-9
	5-3.	Circuit Boards Location	5-11
	5-4.	Schematic Diagrams and Printed Wiring	
		Boards	5-11
	(1)	Schematic Diagram of D Board	5-13
	(2)	Schematic Diagram of A Board	5-19
	(3)	Schematic Diagram of S Board	5-25
	(4)	Schematic Diagrams of N (a), b, c) Board	5-27
	(5)	Schematic Diagram of G Board	5-35
	(6)	Schematic Diagram of US Board	5-39
	(7)	Schematic Diagrams of J, H Boards	5-42
	5-5.	Semiconductors	5-44
6.	EYD	LODED VIEWS	
<b>J</b> .		Chassis	6-1
		Picture Tube	
		Packing Materials	
	6-3		
	6-3.	racking iviaterials	0 3

Note: Hand degauss <u>must be used on stand-by or power-off condition</u>.

This model has an automatic earth magnetism correction function by using an earth magnetism sensor and a LCC coil. When using a hand degauss while monitor (LCC coil) is being operated, it sometimes gets magnetized, and the system may not work properly as a result.

# SECTION 1 **GENERAL**

#### **Precautions**

#### Warning on power connections

Use an appropriate power cord for your local power supply.

Example of plug types





for 100 to 120 V AC for 200 to 240 V AC for 240 V AC only

- i Before disconnecting the power cord, wait at least 30 seconds after turning off the power to allow the static electricity on the screenís surface to discharge.
- i After the power is turned on, the screen is demagnetized (degaussed) for about 3 seconds. This generates a strong magnetic field around the screen which may affect data stored on magnetic tapes and disks placed near the monitor. Be sure to keep magnetic recording equipment, tapes, and disks away from the monitor.

The equipment should be installed near an easily accessible

#### Installation

Do not install the monitor in the following places:

- ï on surfaces (rugs, blankets, etc.) or near materials (curtains,
- draperies, etc.) that may block the ventilation holes i near heat sources such as radiators or air ducts, or in a place
- subject to direct sunlight
- ï in a place subject to severe temperature changes
- i in a place subject to mechanical vibration or shock i on an unstable surface
- ï near equipment which generates magnetism, such as a transformer or high voltage power lines
- i near or on an electrically charged metal surface

#### Maintenance

- ï Clean the screen with a soft cloth. If you use a glass cleaning liquid, do not use any type of cleaner containing an anti-static solution or similar additive as this may scratch the screenís
- i Do not rub, touch, or tap the surface of the screen with sharp or abrasive items such as a ballpoint pen or screwdriver. This type of contact may result in a scratched picture tube.
- i Clean the cabinet, panel and controls with a soft cloth lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent, such as alcohol or

#### Transpotation


When you transport this monitor for repair or shipment, use the original carton and packing materials.

Never grasp the control stick when you transport the monitor.



#### Use of the tilt-swivel


This monitor can be adjusted within the angles shown below. To find the center of the monitoris turning radius, align the center of the monitoris screen with the centering dots on the stand. Hold the monitor at the bottom with both hands when you turn it horizontally or vertically



# Identifying parts and controls


See the pages in parentheses or further details

#### Front



#### To use the control stick

This monitor has a cylindrical swivel control stick. To operate the controls, turn the knob on the left side downward to expose the control buttons. When the control buttons are not needed, turn the knob up to hide the control buttons.



#### 1 RESET (reset) button (page 15)

This button resets the adjustments to the factory settings.

# 2 ASC (auto sizing and centering) button (page 8) This button automatically adjusts the size and centering of the

# 3 INPUT (input) switch (page 8)

This switch selects the HD15 or BNC video input signal.


#### 4 Joystick (page 10)

The joystick is used to display the menu and make adjustments to the monitor, including brightness and contrast

#### 5 ① (power) switch and indicator (pages 7, 15, 19)

This button turns the monitor on and off. The power indicator lights up in green when the monitor is turned on, and either flashes in green and orange, or lights up in orange when the monitor is in power saving mode.

#### Rear



#### 6 AC IN connector (page 6)

This connector provides AC power to the monitor.

# 7 USB (universal serial bus) downstream connectors

Use these connectors to link USB peripheral devices to the

GB

# 8 USB (universal serial bus) upstream connector

Use this connector to link the monitor to a USB compliant

#### 9 Video input 1 connector (HD15) (page 6)

This connector inputs RGB video signals (0.700 Vp-p, positive) and sync signals.



Pin No.	Signal	Pin No.	Signal
1	Red	8	Blue Gro
2	Green	9	DDC + 5
	(Composite Sync	10	Ground
3	on Green)	11	ID (Grou
4	ID (Ground)	12	Bi-Direct Data (SD
5	DDC Ground*	13	H. Sync
6	Red Ground	14	V. Sync
7	Green Ground	15	Data Cloc (SCL)*

\* DDC (Display Data Channel) is a standard of VESA.

#### 10 Video input 2 connector (BNC) (page 6)

This connector inputs RGB video signals (0.700 Vp-p, positive) and sync signals.

# Setup

This monitor works with platforms running at horizontal frequencies between 30 and 121 kHz.


# Step 1:Connect your monitorto your computer

Turn off the monitor and computer before connecting.


#### Note

- ï Do not touch the pins of the video signal cable connector as this might head the pins
- ï When connecting the video signal cable, check the alignment of the connector. Do not force the connector in the wrong way or the pins might bend.

#### ■ Connecting to the HD15 connector



#### ■ Connecting to the five BNC connectors




\* Connect the cables from left to right in the following order: Red-Green-Blue-HD-VD.

#### Note

Plug & Play (DDC) does not apply to the five BNC connectors. If you want to use Plug & Play, connect your computer to the connector using the supplied video signal cable.

#### Step 2: Connect the power cord

With the monitor and computer switched off, first connect the power cord to the monitor, then connect it to a power outlet.



# Step 3: Turn on the monitor and computer

First turn on the monitor, then turn on the computer.



The installation of your monitor is complete. If necessary, use the monitoris controls to adjust the picture.

#### If no picture appears on your screen

- ï Check that the monitor is correctly connected to the computer.
- i If NO INPUT SIGNAL appears on the screen, try changing the input signal (page 8), and confirm that your computer's graphic board is completely seated in the correct bus slot.
- i If you are replacing an old monitor with this model and OUT OF SCAN RANGE appears on the screen, reconnect the old monitor. Then adjust the computer's graphic board so that the horizontal frequency is between 30 n


  i 121 kHz, and the vertical frequency is between 48 n

  i 160 Hz.

For more information about the on-screen messages, see iT rouble symptoms and remediesi on page 17.

# Connecting Universal Serial Bus (USB) compliant peripherals

Your monitor has one upstream and four downstream USB connectors. They provide a fast and easy way to connect USB compliant peripheral devices (such as keyboards, mice, printers and scanners) to your computer using a standardized USB cable. To use your monitor as a hub for your peripheral devices, connect the USBs as illustrated below.



1 Turn on the monitor and computer.

G

7

- Connect your computer to the square upstream connector using the USB cable (not supplied).
- 3 Connect your USB compliant peripheral devices to the rectangular downstream USB connectors.

#### Notes


- ï Not all computers and/or operating systems support USB configurations. Check your computer/s instruction manual to see if you can connect USB devices.
- ï In most cases, USB driver software needs to be installed on the host computer. Refer to the peripheral device(s instruction manual for further details.
- $\ddot{i}$  The monitor functions as a USB hub as long as the monitor is either  $\hat{i}$  on  $\hat{i}$  or in power saving mode.
- i If you connect a keyboard or mouse to the USB connectors and then boot your computer for the first time, the peripheral devices may not function. First connect the keyboard and mouse directly to the computer and set up the USB compliant devices. Then connect them to this monitor.

language (LANG)


1 Press the joystick.

See page 10 for more information on using the joystick.

Selecting the on-screen menu



2 Move the joystick to highlight 7 LANG and press the joystick again.



#### Move the joystick up or down to select a language and press the joystick again.

i ENGLISH

- ï FRAN«AIS: French
- ï DEUTSCH: German
- ï ESPA--OL: Spanish
- ï ITALIANO: İtalian
- ï NEDERLANDS: Dutch
- ï SVENSKA: Swedish
- ї РУССКИЙ: Russian
- ï 日本語: Japanese
- To close the menu

Press the joystick once to return to the main menu, and twice to return to normal viewing. If no buttons are pressed, the menu closes automatically after about 30 seconds.

#### To reset to English

Press the RESET button while the LANGUAGE menu is displayed on the

## Selecting the input signal

You can connect two computers to this monitor using the video input 1 (HD15) and video input 2 (BNC) connectors. To switch between the two computers, use the INPUT switch.

#### Move the INPUT switch.

The currently selected connector (iINP UT 1î: HD15 or ì INPUT 2î: BNC) appears on the screen for a few seconds.



If no signal is input to the selected connector, NO INPUT SIGNAL appears on the screen. After a few seconds, the monitor enters the power saving mode. If this happens, switch to the other connector.

# Automatically sizing and centering the picture (AUTO)

You can easily adjust the picture to fill the screen by pressing the ASC (auto sizing and centering) button.

#### Press the ASC button.

The picture automatically fills the screen.



#### Notes


- This function is intended for use with a computer that provides a full screen picture. It may not work properly if the background color is dark or if the input picture does not fill the screen to the edges.
- The picture will fill the screen to the edges only if the aspect ratio of the picture is 16:10 and the signal is listed on the preset mode timing table in Appendix. Pictures with an aspect ratio other than 16:10 are displayed at their actual resolution and do not fill the screen to the
- ï The displayed image moves for a few seconds while this function is performed. This is not a malfunction.

# CustomizigYour Montor

You can make numerous adjustments to your monitor using the on-screen menu.

## Navigating he menu

Press the joystick to display the main MENU on your screen. See page 10 for more information on using the joystick.



Use the joystick to select one of the following menus.

## 1 CENTER (page 11)

Select the CENTER menu to adjust the picture(s centering or zoom



SIZE/CENTER

# 2 SIZE (page11)

Select the SIZE menu to adjust the pictureis size or



#### 3 GEOM (page 11)

Select the GEOM menu to adjust the pictureís rotation and shape.



#### 4 COLOR (page 11)

Select the COLOR menu to adjust the pictureis color temperature. You can use this to match the monitoris colors to a printed pictureis colors.



#### 5 SCREEN (pge 13)

Select the SCREEN menu to adjust the pictureis quality. You can adjust the landing and moire cancellation effect.



#### 6 CONV (page 14)

Select the CONV menu to adjust the pictureís horizontal and vertical convergence.



#### 7 LANG (page 8)

Select the LANG menu to choose the on-screen menuis language.



DEGAUSS

ON

GB

#### 8 OPTION (page 14)

Select the OPTION menu to adjust the monitoris options. The options

- i degaussing the screen
- ï changing the on-screen menu position
- i locking the controls

# 9 EXIT

Select EXIT to close the menu.

#### ■ Displaying the current input signal

The horizontal and vertical frequencies of the current input signal are displayed under the main MENU. If the signal matches one of this monitoris factory preset modes, the resolution is also displayed.



## thodut criethte c immalt s

thirt horiz and vertical frequencies of thentu

In some cases, even though the aspect ratio of the current input signal is 4:3 or 5:4, the resolution may be displayed with an aspect ratio of 16:10 or 16:9.

9

(continued)

#### ■ Using the joystick

# 1 Display the main MENU and select the menu you want to adjust.

Press the joystick once to display the main MENU. Then move the joystick up, down, left, or right to highlight the desired menu. Press the joystick to select the menu item.



#### 2 Adjust the menu.

Move the joystick up, down, left, or right to make the adjustment.



#### 3 Close the menu.

Press the joystick once to return to the main menu, and twice to return to normal viewing. If no buttons are pressed, the menu closes automatically after about 30 seconds.



#### Resetting the adjustments

Press the RESET button. See page 15 for more information on resetting the adjustments.

#### RESET



# Adjusting the brightness and contrast

Brightness and contrast adjustments are made using a separate BRIGHTNESS/CONTRAST menu.

These settings are stored in memory for the signals from the currently selected input connector.

1 Move the joystick in any direction.

The BRIGHTNESS/CONTRAST menu appears on the screen.



#### If you select the sRGB mode in the COLOR menu

Confirm that the brightness ( 🌣 ) and contrast ( ) values are adjusted respectively to the numbers to be set in the sRGB mode shown in the BRIGHTNESS/CONTRAST menu. If not, press the RESET button (for less than 2 seconds).



Values to be set in the sRGB mode

For more information about using the sRGB mode, see iAdj usting the color of the picture (COLOR) $\hat{i}$  on page 11.

The menu automatically disappears after about 3 seconds.

# Adjusting the centering of the picture (CENTER)

This setting is stored in memory for the current input signal.

1 Press the joystick.

The main MENU appears on the screen.

2 Move the joystick to highlight CENTER and press the joystick again.

The SIZE/CENTER menu appears on the screen.

3 First move the joystick up or down to select for horizontal adjustment, or for vertical adjustment. Then move the joystick left or right to adjust the centering.

# Adjusting the size of the picture (SIZE)

This setting is stored in memory for the current input signal.

1 Press the joystick.

The main MENU appears on the screen.

2 Move the joystick to highlight SIZE and press the joystick again.

The SIZE/CENTER menu appears on the screen.

3 First move the joystick up or down to select 
→ for horizontal adjustment, or 
→ for vertical adjustment. Then move the joystick left or right to adjust the size.

# Enlarging or reducing the picture (ZOOM)

This setting is stored in memory for the current input signal.

1 Press the joystick.

The main MENU appears on the screen.

2 Move the joystick to highlight → SIZE or → CENTER and press the joystick again.
The SIZE/CENTER menu appears on the screen.

3 Move the joystick up or down to select 
(200m), and move the joystick left or right to enlarge or reduce the picture.

#### Note

Adjustment stops when either the horizontal or vertical size reaches its maximum or minimum value.

# Adjusting the shape of the picture (GEOM)

The ( rotation) setting is stored in memory for all input signals.

All other settings are stored in memory for the current input signal.

1 Press the joystick.

The main MENU appears on the screen.

2 Move the joystick to highlight ☐ GEOM and press the joystick again.

The GEOMETRY menu appears on the screen.

3 First move the joystick up or down to select the desired adjustment item. Then move the joystick left or right to make the adjustment.

Select	То
0	rotate the picture
	expand or contract the picture sides
$\Box$	shift the picture sides to the left or right
$\Box$	adjust the picture width at the top of the screen
	shift the picture to the left or right at the top of the screen

G

# Adjusting the color of the picture (COLOR)

The COLOR settings allow you to adjust the picture's color temperature by changing the color level of the white color field. Colors appear reddish if the temperature is low, and bluish if the temperature is high. This adjustment is useful for matching the monitor's color to a printed picture's colors.

1 Press the joystick.

The main MENU appears on the screen.

2 Move the joystick to highlight COLOR and press the joystick again.

The COLOR menu appears on the screen.

3 Move the joystick left or right to select the adjustment mode.

There are three types of adjustment modes, EASY, EXPERT, and sRGB.

Adjust the selected mode according to the instructions on the next page.

You can set the color temperature in EASY or EXPERT mode for each of the video input connectors.

(continued)

10

#### ■ EASY mode

In EASY mode, you can fine tune the color temperature by changing the three preset temperatures 6 50 00K, 6500K, or



1 Move the joystick up or down to select the color temperature row 1. Then move the joystick left or right to select a color temperature.

The preset color temperatures are 5000K, 6500K, and 9300K. The default setting is 9300K. The whites will change from a bluish hue to a reddish hue as the temperature is lowered to 6500K and 5000K.


2 If necessary, fine tune the color temperature. Move the joystick up or down to select the color temperature row 2. Then move the joystick left or right to fine tune the color temperature.

If you fine tune the color temperature, the new color settings are stored in memory for each of the three color temperatures and item 1 of the on-screen menu changes as follows.

- ï [5000K]→[ **∴** 1]
- ï [6500K]→[ : 2]
- ï [9300K]→[:3]

#### ■ EXPERT mode

You can make additional adjustments to the color in greater detail by selecting the EXPERT mode.



- 1 Move the joystick up or down to select the color temperature row 1. Then move the joystick left or right to select a color temperature.
- 2 Move the joystick up or down to select the adjustment item 2. Then move joystick left or right to adjust the BIAS (black level). This adjusts the dark areas of an image
- 3 Move the joystick up or down to select the adjustment item 3. Then move the joystick left or right to adjust the GAIN (white level).

This adjusts the light areas of an image.

You can adjust the R (red), G (green), B (blue) component of the input signal when making changes to items 2 and 3.

If you fine tune the color temperature, the new color settings are stored in memory for each of the three color temperatures and item 1 of the on-screen menu change as follows

- ï [5000K]→[**1**]
- ï [6500K]→[ 32]

# ï [9300K]→[:3]

#### ■ sRGB mode

The sRGB color setting is an industry standard color space protocol designed to correlate the displayed and printed colors of sRGB compliant computer products. To adjust the colors to the sRGB profile, simply select the sRGB mode in the COLOR menu. Once you select the sRGB mode, the brightness ( 🔆 ) and contrast (1) values are automatically set to the values to be set in the sRGB mode.



In order to display the sRGB colors correctly ( $\gamma = 2.2, 6500K$ ), confirm that:

- i the brightness ( O ) and contrast ( ) values are adjusted respectively to the numbers shown in the BRIGHTNESS/ CONTRAST menu. If not, press the RESET button (for less than 2 seconds). For information on how to change the brightness and contrast, see i Adjusting the brightness and contrastî on page 10.
- i the color settings of your computer are set to the sRGB profile.

Your computer and other connected products (such as a printer), must be sRGB compliant.

#### Restoring the color from the EASY or sRGB menus (IMAGE RESTORATION function)

The colors of most display monitors tend to gradually lose brilliance over several years of service. The IMAGE RESTORATION feature found in the EASY and sRGB menus allows you to restore the color to the original factory quality levels.

- Move the joystick left or right to select EASY or sRGB mode.
- 2 First move the joystick up or down to select (IMAGE RESTORATION). Then move the joystick to the right.

The picture disappears while the color is being restored (about 2 seconds). After the color is restored, the picture reappears on the screen again.

#### Notes

i Before using this feature, the monitor must be in normal operation mode (green power indicator on) for at least 30 minutes. If the monitor goes into power saving mode, you must return the monitor to normal operation mode and wait for 30 minutes for the monitor to be ready. You may need to adjust your computeris power saving settings to keep the monitor in normal operation mode for the full 30 minutes. If the monitor is not ready, the following message will appear



ï The monitor may gradually lose its ability to perform this function due to the natural aging of the picture tube

## Adjusting the quality of the picture (SCREEN)

The SCREEN settings allow you to adjust the quality of the picture by controlling the moire and landing.

- i If the color is irregular at the corners of the screen, adjust the landing.
- ï If elliptical or wavy patterns appear on the screen, cancel the

The CANCEL MOIRE and MOIRE ADJUST settings are stored in memory for the current input signal. All other settings are stored in memory for all input signals.

1 Press the joystick.

The main MENU appears on the screen.

2 Move the joystick to highlight III SCREEN and press the joystick again.

The SCREEN menu appears on the screen.

3 First move the joystick up or down to select the desired adjustment item. Then move the joystick left or right to make the adjustment.

GB

Select	То
LANDING	reduce any color irregularities in the screenís top left corner to a minimum.
LANDING	reduce any color irregularities in the screenís top right corner to a minimum.
LANDING	reduce any color irregularities in the screenís bottom left corner to a minimum.
LANDING	reduce any color irregularities in the screenís bottom right corner to a minimum.
CANCEL MOIRE*	turn the moire cancellation function ON or OFF.
	(MOIRE ADJUST) appears in the menu when you select ON.
MOIRE ADJUST	adjust the degree of moire cancellation until the moire is at a minimum.

\* Moire is a type of natural interference which produces soft, wavy lines on your screen. It may appear due to interference between the pattern of the picture on the screen and the phosphor pitch pattern of the

Example of moire



The picture may become fuzzy when CANCEL MOIRE is set to ON

12 13

## Adjusting the convergence (CONV)

The CONV settings allow you to adjust the quality of the picture by controlling the convergence. The convergence refers to the alignment of the red, green, and blue color signals. If you see red or blue shadows around letters or lines, adjust the

convergence.

These settings are stored in memory for all input signals.

#### 1 Press the joystick.

The main MENU appears on the screen.

2 Move the joystick to highlight IF CONV and press the joystick again.

The CONVERGENCE menu appears on the screen.

3 First move the joystick up or down to select the desired adjustment item. Then move the joystick left or right to make the adjustment.

Select	То
NR.	horizontally shift red or blue shadows
<b>÷</b>	vertically shift red or blue shadows
<b>₹ TOP</b> V CONVER TOP	vertically shift red or blue shadows at the top of the screen
<b>∌ BOT</b> V CONVER BOTTOM	vertically shift red or blue shadows at the bottom of the screen

### Additional settings (OPTION)

You can manually degauss (demagnetize) the monitor, change the menu position, and lock the controls.

#### 1 Press the joystick.

The main MENU appears on the screen.

2 Move the joystick to highlight A OPTION and press the joystick again.

The OPTION menu appears on the screen.

3 Move the joystick up or down to select the desired adjustment item.

Adjust the selected item according to the following instructions.

#### Degaussing the screen

The monitor is automatically demagnetized (degaussed) when the power is turned on.

To manually degauss the monitor, first move the joystick up or down to select 🖰 (DEGAUSS). Then move the joystick to the right.

The screen is degaussed for about 3 seconds. If a second degauss cycle is needed, allow a minimum interval of 20 minutes for the

#### ■ Changing the menuis position

Change the menuis position if it is blocking an image on the

To change the menuis on-screen position, first move the joystick up or down to select - (OSD H POSITION) for horizontal adjustment, or 🗊 (OSD V POSITION) for vertical adjustment. Then move the joystick left or right to shift the on-screen menu.

### ■ Locking the controls

To protect adjustment data by locking the controls, first move the joystick up or down to select On (CONTROL LOCK). Then move the joystick to the right, to select

Only the ① (power) switch, EXIT, and On (CONTROL LOCK) of the POPTION menu will operate. If any other items are selected, the Om mark appears on the screen.

#### To cancel the control lock

Repeat the procedure above and set On (CONTROL LOCK) to OFF.

## Resetting the adjustments

This monitor has the following three reset methods. Use the RESET button to reset the adjustments.

#### RESET



#### Resetting a single adjustment item

Use the joystick to select the adjustment item you want to reset, and press the RESET button.

#### Resetting all of the adjustment data for the current input signal

Press the RESET button when no menu is displayed on the screen. Note that the following items are not reset by this method:

- ï on-screen menu language (page 8)
- i adjustment mode in the COLOR menu (EASY, EXPERT, sRGB) (page 11)
- i on-screen menu position (page 14)
- ï control lock (page 14)

#### Resetting all of the adjustment data for all input signals

Press and hold the RESET button for more than 2 seconds.

The RESET button does not function when Om (CONTROL LOCK) is

# **Technical Features**

## Power saving function

This monitor meets the power-saving guidelines set by VESA, ENERGY STAR, and NUTEK. If the monitor is connected to a computer or video graphics board that is DPMS (Display Power Management Signaling) compliant, the monitor will automatically reduce power consumption in three stages as shown below.

Power mode	Power consumption*	① (power) indicator
normal operation	≤ 170 W	green
1 standby	≤ 15 W	green and orange alternate
2 suspend (sleep)**	≤ 15 W	green and orange alternate
3 active off*** (deep sleep)**	≤ 1 W	orange
power off	0 W	off


- Figures reflect power consumption when no USB compatible peripherals are connected to the monitor.
- \*\* 1 Sleepî and 1 deep sleepî are power saving modes defined by the Environmental Protection Agency.
- \*\*\* When your computer enters power saving mode, the input signal is cut and NO INPUT SIGNAL appears on the screen before the monitor enters active off mode. After a few seconds, the monitor enters power saving mode.

# **Troubleshooting**

Before contacting technical support, refer to this section.

# If thin lines appear on your screen (damper wires)

The visible lines on your screen especially when the background screen color is light (usually white), are normal for the Trinitron monitor. This is not a malfunction. These are shadows from the damper wires used to stabilize the aperture grille. The aperture grille is the essential element that makes a Trinitron picture tube unique by allowing more light to reach the screen, resulting in a brighter, more detailed picture.



# On-screen messages

If there is something wrong with the input signal, one of the following messages appears on the screen.

#### If NO INPUT SIGNAL appears on line 1

This indicates that no signal is input from the selected connector.



#### 2 The selected connector

This message shows the currently selected connector (INPUT 1 or INPUT 2).

#### 3 The remedies

One or more of the following messages may appear on the screen

- i If ACTIVATE BY COMPUTER appears on the screen, try pressing any key on the computer or moving the mouse, and confirm that your computer's graphic board is completely seated in the correct bus slot.
- i If CHECK INPUT SELECTOR appears on the screen, try changing the input signal (page 8).
- i If CHECK SIGNAL CABLE appears on the screen, check that the monitor is correctly connected to the computer (page 6).

#### If OUT OF SCAN RANGE appears on line 1

This indicates that the input signal is not supported by the monitor's specifications.



# 2 The selected connector and the frequencies of the current input signal

This message shows the currently selected connector (INPUT 1 or INPUT 2). If the monitor recognizes the frequencies of the current input signal, the horizontal and vertical frequencies are also displayed.

#### 3 The remedies

CHANGE SIGNAL TIMING appears on the screen. If you are replacing an old monitor with this monitor, reconnect the old monitor. Then adjust the computer's graphic board so that the horizontal frequency is between 30 - 121 kHz, and the vertical frequency is between 48 - 160 Hz.

For more information, see ì Trouble symptoms and remedies  $\hat{\imath}$  on page 17.

#### Trouble symptoms and remedies

If the problem is caused by the connected computer or other equipment, please refer to the connected equipment's instruction manual. Use the self-diagnosis function (page 19) if the following recommendations do not resolve the problem.

Symptom	Check these items		
No picture			
If the $\ensuremath{\textcircled{1}}$ (power) indicator is not lit	<ul> <li>T Check that the power cord is properly connected.</li> <li>T Check that the ① (power) switch is in the ì onî position.</li> </ul>		
If the NO INPUT SIGNAL message appears on the screen, or if the $0$ (power) indicator is either orange or alternating between green and orange	<ul> <li>T Check that the video signal cable is properly connected and all plugs are firmly seated in their sockets (page 6).</li> <li>T Check that the INPUT switch setting is correct (page 8).</li> <li>Check that the video input connector's pins are not bent or pushed in.</li> <li>Problems caused by the connected computer or other equipment</li> <li>The computer is in power saving mode. Try pressing any key on the keyboard or moving the mouse.</li> </ul>		
	<ul> <li>i Check that the computer's power is io n.î</li> <li>i Check that the graphic board is completely seated in the proper bus slot.</li> </ul>		
If the OUT OF SCAN RANGE message appears on the screen	Problems caused by the connected computer or other equipment  i Check that the video frequency range is within that specified for the monitor. If you replaced an old monitor with this monitor, reconnect the old monitor and adjust the frequency range to the following.  Horizontal: 30 ii 121 kHz  Vertical: 48 ii 160 Hz		
If no message is displayed and the ① (power) indicator is green or flashing orange	ï Use the Self-diagnosis function (page 19).		
Picture flickers, bounces, oscillates, or is scrambled	<ul> <li>I Isolate and eliminate any potential sources of electric or magnetic fields such as other monitors, laser printers, fluorescent lighting, televisions, or electric fans.</li> <li>I Move the monitor away from power lines.</li> <li>I Try plugging the monitor into a different AC outlet, preferably on a different circuit.</li> <li>I Try turning the monitor 90° to the left or right.</li> </ul>		
	■Problems caused by the connected computer or other equipment  i Check your graphic board manual for the proper monitor setting.  i Confirm that the graphics mode and the frequency of the input signal are supported by this monitor (Appendix). Even if the frequency is within the proper range, some graphic boards may have a sync pulse that is too narrow for the monitor to sync correctly.  i Adjust the computeris refresh rate (vertical frequency) to obtain the best possible picture.		
Picture is fuzzy	Adjust the brightness and contrast (page 10).     Degauss the monitor* (page 14).     If CANCEL MOIRE is ON, the picture may become fuzzy. Decrease the moire cancellation effect or set CANCEL MOIRE to OFF (page 13).		
Picture is ghosting	Eliminate the use of video cable extensions and/or video switch boxes.     Check that all plugs are firmly seated in their sockets.		
Picture is not centered or sized properly	Press the ASC button (page 8).     Adjust the size or centering (page 11). Note that some video modes do not fill the screen to the edges.		
Edges of the image are curved	ï Adjust the geometry (page 11).		

(continued)

17

16

Symptom	Check these items
Wavy or eliptical pattern(more) is visible	T Set CANCEL MOIRE to ON and adjust the degree of moire cancellation until the moire is at a minimum (page 13).
	■Problems caused by the connected computer σ other equipment ï Change your desktop pattern.
Color is not uniform	<ul> <li>i Degauss the monitor* (page 14). If you place equipment that generates a magnetic field, such as a speaker, near the monitor, or if you change the direction the monitor faces, color may lose uniformity.</li> <li>i Adjust the landing (page 13).</li> </ul>
White does not lookwhite	Adjust the color temperature (page 11).     Check that the five BNC connectors are connected in the correct order (page 6).
Letters and lines show red or blue shadows at the edges	ï Adjust the convergence (page 14).
Monitor buttons do not operate (On appears on the screen)	ï If the control lock is set to ON, set it to OFF (page 14).
IMAGE RESTORATION function does not operate  COLOR  EASY EXPERT SRGB  *5000K *6500K *9300K  *5000K *9300K  *5000K *9300K  AVAILABLE  AFTER WARM UP	<ul> <li>i Before using this function, the monitor must be in normal operation mode (green power indicator on) for at least 30 minutes. For more information on using the IMAGE RESTORATION function, see page 13.</li> <li>i Adjust the computer's power saving settings to keep the monitor in normal operation mode for more than 30 minutes.</li> <li>i The monitor may gradually lose its ability to perform this function due to the natural aging of the picture tube.</li> </ul>
USB peripherals do not function	<ul> <li>Check that the appropriate USB connectors are securely connected (page 7).</li> <li>Check that the ① (power) switch is in the ì onî position.</li> </ul>
	■Problems caused by the cornected computer \( \sigma \) other equipment  i Check that the power of any self-powered USB compliant peripheral devices is ion \( \text{i} \) i Install the latest version of the device driver on your computer. Contact your deviceis manufacturer for information about the appropriate device driver.  i If your USB compliant keyboard or mouse does not function, connect them directly to your computer, reboot your computer, and make any necessary adjustments to the USB settings. Then reconnect the keyboard or mouse to the monitor. If you connect a keyboard or mouse to the USB connectors and then boot your computer for the first time, the peripheral devices may not function.
A hum is heard right after the power is turned on	ï This is the normal sound of the auto-degauss cycle. When the power is turned on, the monitor is automatically degaussed for 3 seconds.

\* If a second degauss cycle is needed, allow a minimum interval of 20 minutes for the best result. A humming noise may be heard, but this is not a

#### Displaying this monitoris name, serial number, and date of manufactue.


While the monitor is receiving a video signal, press and hold the joystick for more than 5 seconds to display this monitoris information box.





## Self-diagnosis function

This monitor is equipped with a self-diagnosis function. If there is a problem with your monitor or computer(s), the screen will go blank and the ① (power) indicator will either light up green or flash orange. If the ① (power) indicator is lit in orange, the computer is in power saving mode. Try pressing any key on the keyboard or moving the mouse.



#### ■ If the ① (power) indicator is green

- 1 Disconnect any plugs from the video input 1 and 2 connectors, or turn off the connected computer(s).
- 2 Press the ① (power) button twice to turn the monitor off and then on.
- 3 Move the joystick to the right for 2 seconds before the monitor enters power saving mode.



If all four color bars appear (white, red, green, blue), the monitor is working properly. Reconnect the video input cables and check the condition of your computer(s).

If the color bars do not appear, there is a potential monitor failure. Inform your service personal of the monitoris condition.

#### ■ If the ① (power) indicator is flashing orange

Press the  $\ensuremath{\boxdot}$  (power) button twice to turn the monitor off

If the ① (power) indicator lights up green, the monitor is working properly.

If the ① (power) indicator is still flashing, there is a potential monitor failure. Count the number of seconds between orange flashes of the ① (power) indicator and inform your service personal of the monitoris condition. Be sure to note the model name and serial number of your monitor. Also note the make and model of your computer and graphic board.

# **Specifications**

0.23 ñ 0.27 mm aperture grille pitch 24 inches measured diagonally

90-degree deflection

FD Trinitron Approx. 482.1 × 308.2 mm (w/h) Viewable image size

 $(19 \times 12^{-1}/4 \text{ inches})$ 22.5" viewing image Resolution Maximum (16:10) Horizontal: 2304 dots Vertical: 1440 lines Maximum (4:3)

Horizontal: 2048 dots Vertical: 1536 lines Recommended (16:10) Horizontal: 1920 dots Vertical: 1200 lines Video signal

Input signal levels Analog RGB: 0.700 Vp-p

> (positive), 75 Ω SYNC signal

H/V separate or composite sync: TTL 2 kΩ, Polarity free

Sync on Green: 0.3 Vp-p

(negative) Standard image area

Approx. 474 × 296 mm (w/h)  $(18^{3}/4 \times 11^{3}/4 \text{ inches})$ 

Approx. 395 × 296 mm (w/h)  $(15^{5}/8 \times 11^{3}/4 \text{ inches})$ 

5:4

Approx. 370 × 296 mm (w/h)  $(14^{5/8} \times 11^{3/4} \text{ inches})$ 

Deflection frequency\* Horizontal: 30 to 121 kHz

Vertical: 48 to 160 Hz

AC input voltage/current 100 to 240 V, 50/60 Hz, 2.2 ñ 1.2 A Power consumption Approx. 170 W (with no USB devices

connected) Operating temperature 10∞C to 40∞C

Approx. 571.5 × 500 × 522.5 mm (w/h/ Dimensions

d)  $(22^{1/2} \times 19^{3/4} \times 20^{5/8} \text{ inches})$ Approx. 42 kg (92 lb 10 oz) Plug and Play DDC1/DDC2B/DDC2Bi, GTF\*\*

Supplied accessories This operating instruction

\* Recommended horizontal and vertical timing condition ï Horizontal sync width duty should be more than 4.8% of

total horizontal time or 0.8 µs, whichever is larger. ï Horizontal blanking width should be more than 2.3 μsec. ï Vertical blanking width should be more than 450 µsec.


\*\* If the input signal is Generalized Timing Formula (GTF) compliant, the GTF feature of the monitor will automatically provide an optimal image for the screen.

Design and specifications are subject to change without notice.

19 18

# Self-diagnosis function

This monitor is equipped with a self-diagnosis function. If there is a problem with your monitor or computer(s), the screen will go blank and the ① (power) indicator will either light up green or flash orange. If the ① (power) indicator is lit in orange, the computer is in power saving mode. Try pressing any key on the keyboard or moving the mouse.



#### ■ If the ① (power) indicator is green

- 1 Disconnect any plugs from the video input 1 and 2 connectors, or turn off the connected computer(s).
- 2 Press the ① (power) button twice to turn the monitor off and then on.
- 3 Move the joystick to the right for 2 seconds before the monitor enters power saving mode.



If all four color bars appear (white, red, green, blue), the monitor is working properly. Reconnect the video input cables and check the condition of your computer(s).

If the color bars do not appear, there is a potential monitor failure. Inform your authorized Sony dealer of the monitor's condition.

#### ■ If the ① (power) indicator is flashing orange

Press the ① (power) button twice to turn the monitor off and then on.

If the ① (power) indicator lights up green, the monitor is working properly.

If the ① (power) indicator is still flashing, there is a potential monitor failure. Count the number of seconds between orange flashes of the ① (power) indicator and inform your authorized Sony dealer of the monitor's condition. Be sure to note the model name and serial number of your monitor. Also note the make and model of your computer and graphic board.

# **Specifications**

Resolution

0.23 - 0.27 mm aperture grille pitch

24 inches measured diagonally 90-degree deflection

FD Trinitron

Viewable image size Approx. 482.1 × 308.2 mm (w/h)

 $(19 \times 12^{-1}/4 \text{ inches})$ 19.8" viewing image

Maximum (16:10)

Horizontal: 2304 dots Vertical: 1440 lines

Maximum (4:3)

Horizontal: 2048 dots

Vertical: 1536 lines

Recommended (16:10) Horizontal: 1920 dots

Vertical: 1200 lines

Input signal levels Video signal

Analog RGB: 0.700 Vp-p (positive), 75 Ω

SYNC signal

H/V separate or composite sync:

TTL 2 kΩ, Polarity free

Sync on Green: 0.3 Vp-p

(negative) Standard image area

16:10

Approx. 474 × 296 mm (w/h)

 $(18^{3}/4 \times 11^{3}/4 \text{ inches})$ 

Approx. 395 × 296 mm (w/h)

 $(15^{5}/8 \times 11^{3}/4 \text{ inches})$ 

Approx. 370 × 296 mm (w/h)

 $(14^{5/8} \times 11^{3/4} \text{ inches})$ 

Deflection frequency\*

Horizontal: 30 to 121 kHz

Vertical: 48 to 160 Hz

AC input voltage/current 100 to 240 V, 50/60 Hz, 2.2 - 1.2 A

Power consumption Approx. 170 W (with no USB devices connected)

10°C to 40°C

Operating temperature Dimensions

Approx. 571.5 × 500 × 522.5 mm (w/h/ d)  $(22^{1/2} \times 19^{3/4} \times 20^{5/8} \text{ inches})$ 

Approx. 42 kg (92 lb 10 oz) Mass

Plug and Play DDC1/DDC2B/DDC2Bi, GTF\*\*

Supplied accessories See page 6


\* Recommended horizontal and vertical timing condition

- . Horizontal sync width duty should be more than 4.8% of
- total horizontal time or 0.8 µs, whichever is larger.
- · Horizontal blanking width should be more than 2.3 µsec. Vertical blanking width should be more than 450 μsec.
- \*\* If the input signal is Generalized Timing Formula (GTF) compliant, the GTF feature of the monitor will automatically provide an optimal image for the screen.


Design and specifications are subject to change without notice.

# SECTION 2 DISASSEMBLY


# 2-1. CABINET ASSY REMOVAL




# 2-2. D BOARD REMOVAL




# 2-3. G BOARD REMOVAL




# 2-4. A BOARD AND I/O TERMINAL BOARD ASSY REMOVAL




# 2-5. S BOARD REMOVAL




# 2-6. N BOARD REMOVAL



# 2-7. SERVICE POSITION




# 2-8. PICTURE TUBE REMOVAL



# 2-9. CONTROL BLOCK ASSY REMOVAL


X Remove the picture tube. (Refer to 2-8.)




# • REMOVAL OF ANODE-CAP

NOTE: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon painted on the CRT, after removing the anode.

# REMOVING PROCEDURES



1 Turn up one side of the rubber cap in the direction indicated by the arrow a.




② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow ⓑ.



When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ©.


# • HOW TO HANDLE AN ANODE-CAP

- ① Don't scratch the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to damage inside of anodecaps!
  - A material fitting called as shatter-hook terminal is built in the rubber.
- ③ Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or damage the rubber.







# 2-10. J BOARD REMOVAL



# 2-11. US BOARD REMOVAL



# 2-12. HARNESS LOCATION



# SECTION 3 SAFETY RELATED ADJUSTMENT

When replacing or repairing the shown below table, the following operational checks must be performed as a safety precaution against X-rays emissions from the unit.

	Part Replaced (►)
HV ADJ	RV901

		Part Replaced ( <b>∠</b> )
HV Regulator Circuit Check	D Board	IC901, R923, R924, R929, R943, T902(FBT) • Mounted D Board
HV Protector Circuit Check	D Board	C922, C926, D912, D915, D921, Q907, Q908, R921, R922, R932, R937, R939, T902(FBT) • Mounted D Board
Beam Current Protector Circuit Check	D Board N Board	C921, C933, D901, D913, R920, R928, R930, R931, T902(FBT) • Mounted D Board IC001, R031, R032 • Mounted N Board

<sup>\*</sup> Confirm one minute after turning on the power.

# a) HV Regulator Circuit Check

1) Enter black crosshatch signal (black on white background), and check that high voltage is in the specified range.

[Specification]:  $28.50 \pm 0.10 \text{ kV}$ 

2) Check that the voltage of D912 cathode on the D board is 29.0 V or more.

## b) HV Protector Circuit Check

- 1) Enter black crosshatch signal (black on white background).
- 2) Apply the specified voltage to the D912 cathode on the D board, and check that high voltage is 0.1 kV or less.

[Specification]: 34.00 + 0.00 / - 0.05 V

# c) Beam Current Protector Circuit Check (1st Protector): D Board

- 1) Apply 4.5 V DC to CN504 <sup>(1)</sup> pin on the D board, and check high voltage value.
- 2) Connect constant current source to a section between T902 (FBT) ① pin and ② pin (GND) on the D board, and check that high voltage checked in 1) lowers by 1.50 kV or more when the specified current flows to the ① pin.

[Specification]: 2.00 + 0.00 / - 0.01 mA

# d) Beam Current Protector Circuit Check (2nd Protector): D Board

1) Connect constant current source to a section between T902 (FBT) ① pin and ② pin (GND) on the D board, and check that the voltage of CN504 ② pin becomes 0 V or less when the specified current flows to the ① pin.

[Specification]: 1.63 + 0.00 / - 0.01 mA

# e) Beam Current Protector Circuit Check

# : G Board

- 1) Apply 264 V AC.
- 2) Enter about 5 V to CN650 (4) pin on the G board, and check that the output voltage of CN653 (2) pin is about 15 V.
- 3) Enter about  $0 \pm 0.2$  V to CN650 (4) pin, and check that the output voltage of CN653 (2) pin becomes 1.0 V or less.

# f) Beam Current Protector Circuit Check

## : N Board

1) Check that the protector operates, when the voltage of CN010 <sup>(6)</sup> pin on the N board is lowered to 0 V or less (for more than 2 seconds).

# SECTION 4 ADJUSTMENTS

Note: Hand degauss must be used on stand-by or power-off condition.

This model has an automatic earth magnetism correction function by using an earth magnetism sensor and a LCC coil. When using a hand degauss while monitor (LCC coil) is being operated, it sometimes gets magnetized, and the system may not work properly as a result.

## Landing Rough Adjustment

- 1. Enter the full white signal. (or the full black dots signal).
- 2. Adjust the contrast to the maximum.
- 3. Make the screen monogreen.

Note: Off the outputs from R ch and B ch of SG.

- 4. Reverse the DY, and adjust coarsely the purity magnet so that a green raster positions in the center of screen.
- 5. Adjust the tilt of DY, and fix lightly with a clamp.

Note: "TILT" = "128".

# • Landing Fine Adjustment

- 1. Put the set inside the Helmholtz coil. ("LCC SW" = "12")
- 2. Input the single green signal and set the "CONTRAST" = "255".

Note: After the W/B adjustment with 9300K, measure an average of  $\Sigma$ Ik when a full white signal is entered in the CONT MAX/BRT CENT status. Then make adjustment so that the specified screen can be attained after aging for 2 hours with Ik equivalent to 30% of the average value.

Demagnetize the metal part of the chassis with the hand degausser and coil degausser, and the CRT surface with the hand degausser.

Input AC 230V to AC IN, turn on and off the power to perform auto degaussing. (Perform auto degaussing by setting "FUNCTION SW" = 1. Return to the original value after use.)

Demagnetize the CRT surface with the hand degausser again.

## Note:

(1) Hand degauss <u>must be used on stand-by or power-off condi</u>tion.

This model has an automatic earth magnetism correction function by using an earth magnetism sensor and a LCC coil. When using a hand degauss while monitor (LCC coil) is being operated, it sometimes gets magnetized, and the system may not work properly as a result.

- (2) Adjust in a non-magnetic field.
- (3) If adjusting in a magnetic fields, add the shift from the non-magnetic field in your estimation.
- Attach the wobbling coil to the designated part of the CRT neck.
- Attach the sensor of the landing adjustment unit on the CRT surface.
- Adjust the DY position and purity, and the DY tilt, and landing of the center and 4 corners with the landing checker.
   After adjustment, set "LCC SW" to "13".

 Write terrestrial magnetism sensor reading VX and VY to "LCC VX" and LCC VY" respectively. Adjust the landing by moving "LCC NS", "LCC LT", "LCC LB", "LCC RT" and "LCC RB". However, the register adjustment must be limited within the following range.

"LCC NS" 128  $\pm$  45 "LCC LT", "LCC LB", "LCC RT", "LCC RB" 128  $\pm$  40

Save the service data.

<Specifications>

Adjust so that the green is within the specification given right.

4 corner adjust target : within  $\pm 1$ 

The red and blue must be within the specification given right with respect to the green.

A difference between red and blue must be within the specification given right.

$0 \pm 3$	$0 \pm 7.5$	$0 \pm 3$	
$0 \pm 3$	$0 \pm 7.5$	$0 \pm 3$	
0 ± 3	$0 \pm 7.5$	$0 \pm 3$	
		(µr	n)
± 6	± 6	(μr ±6	n) 
± 6 ± 6	± 6 ± 6		n)   

(µm)

		(μm)
10	10	10
10	7	10
10	10	10

- \* Adjustment and measurement should be made at the points one inch inside the fluorescent screen.
- 7. Tighten DY screw.

Note: Torque  $22 \pm 2$  kg.cm  $(2.2 \pm 0.2 \text{ Nm})$  auto degauss it.

- 8. For the up/down swing, swing the DY and insert a wedge so that the up and down pins are equal at the top and bottom. Adjust the H.TRP VR of DY so that the horizontal trapezoid is equal at the left and right. Insert the wedge firmly so that the DY does not shake.
- 9. Check the landing of each corner, and if it does not satisfy the specification, adjust the landing of four corners using "LCC LT", "LCC LB", "LCC RT" and "LCC RB".


However, the register adjustment must be limited within the following range.

"LCC NS" 128 
$$\pm$$
 15 "LCC LT", "LCC LB", "LCC RT", "LCC RB" 128  $\pm$  45

After adjustment, save the service data.

- 10. Remove the sensor and wobbling coil.
- Switch the signal to R.G.B., and check that each color is pure.
- 12. Check that the DY is not tilting, and fix the purity Mg with a white pen. Fix wedges with RTV.


Connect the communication cable of the computer to the connector located on the D board. Run the service software and then follow the instruction.




\*The parts above (1) and 2) are necessary for DAS adjustment.

# • Convergence Rough Adjustment


- (1) Receive an image of the white crosshatch signals (white lines on black).
- (2) Place the protrusions of the 6-fold poles magnet attached to the CRT neck upon each other.
- (3) Make rough adjustment of the H and V direction convergence by using 4-fold poles magnet.



\* Set so that the protruding parts of the 2 magnet rings agree with each other.



# • Convergence Specification



fH	70kHz≦	70kHz >
Α	0.24 mm	0.24 mm
В	0.24 mm	0.28 mm
С	0.28 mm	0.32 mm

# • White Balance Adjustment Specification

1. 9300K

 $x = 0.283 \pm 0.015$   $y = 0.298 \pm 0.015$ (All White)

2. 6500K

 $x = 0.313 \pm 0.015$   $y = 0.329 \pm 0.015$ (All White)


3. 5000K

 $x = 0.346 \pm 0.015$ 

 $y = 0.359 \pm 0.015$ 

(All White)

# Vertical and Horizontal Position and Size Specification




MODE	4:3	5:4
Α	395	370
В	296	296


MODE	16:9	16 : 10
Α	474	266
В	474	296


## Focus adjustment


Adjust the focus volume 1 and 2 for the optimum focus.





# SECTION 5 DIAGRAMS
















# 5-2. FRAME SCHEMATIC DIAGRAM



# 5-3. CIRCUIT BOARDS LOCATION



# 5-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

## Note:

- All capacitors are in  $\mu F$  unless otherwise noted. (pF:  $\mu \mu F$ ) Capacitors without voltage indication are all 50 V.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4 W (CHIP : 1/10 W)

· All resistors are in ohms.

• : nonflammable resistor.

: fusible resistor.

Δ : internal component.

All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

•  $\perp$  : earth-ground.

• + : earth-chassis.

The components identified by 

in this basic schematic diagram
have been carefully factory-selected for each set in order to
satisfy regulations regarding X-ray radiation.

Should replacement be required, replace only with the value originally used.

- When replacing components identified by , make the necessary adjustments indicated. (See page 3-1)
- When replacing the part in below table, be sure to perform the related adjustment.

Note: The components identified by shading and mark ∆ are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un tramé et une marque \(\Delta\) sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- All voltages are in V.
- Readings are taken with a 10 M digital multimeter.
- · Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- \* : Can not be measured.
- · Circled numbers are waveform references.
- === : B + bus.

5-11

• ===: B - bus.

Divided circuit diagram

One sheet of N board circuit diagram is divided into three sheets, each having the code N-ⓐ to N-ⓒ. For example, the destination (ab1)on the code N-ⓐ sheet is connected to (ab1)on the N-ⓑ sheet.



	Part Replaced (►)
HV ADJ	RV901

		Part Replaced ( <b>△</b> )
HV Regulator Circuit Check	D Board	IC901, R923, R924, R929, R943, T902(FBT) • Mounted D Board
HV Protector Circuit Check	D Board	C922, C926, D912, D915, D921, Q907, Q908, R921, R922, R932, R937, R939, T902(FBT) • Mounted D Board
Beam Current Protector Circuit Check	D Board N Board	C921, C933, D901, D913, R920, R928, R930, R931, T902(FBT) • Mounted D Board IC001, R031, R032 • Mounted N Board


# Terminal name of semiconductors in silk screen printed circuit (\*)

	Device	Printed symbol	Terminal name	Circuit
1	Transistor	_	Collector	
Ľ	Transistor.		Base Emitter	
2	Transistor	_	Collector	
_			Base Emitter	
3	Diode		Cathode - Anod	le
4	Diode	T	Cathode Anode (NC)	<u>\$</u>
			Cathode	→ .
(5)	Diode		Anode (NC)	
6	Diode	_	Common	
•	Diode	•	Anode Cathode	
7)	Diode	_	Common	
			Anode Cathode Common	
8	Diode	T	Anode Anode	
		-	Common	┦
9	Diode	_	Anode Anode	6 6
(10)	Diode	_	Common	
		•	Cathode Cathode	
11)	Diode	_	Common	1,,,,,
			Cathode Cathode	
12	Diode		Anode Anode Cathode Cathode	
(13)	Transistor (FET)		Drain Source Gate	
14)	Transistor (FET)	H	Drain Source Gate	so so
(15)	Transistor (FET)		□ Source □ Drain □ Gate	DO DO DO SO
16	Transistor		☐ Emitter☐ Collector☐ Base	
-	Discrete ser	miconductot		-

(Chip semiconductors that are not actually used are included.)


5-12

Ver.1.6






# • D BOARD WAVEFORMS



# • D BOARD SEMICONDUCTOR LOCATION

				, , , , , , , , , , , , , , , , , , ,	
IC	DIODE				
(Conductor) (Component) IC501 D-4 IC502 A-1 A-5 IC503 C-4 IC504 D-5 D-1 IC701 A-5 A-1 IC901 B-3  TRANSISTOR		D504 D505 D506 D507 D508 D509 D510 D511 D512 D513	(Conductor) Side D-5 A-1 B-4 A-2 A-3 B-2 A-1 A-2 B-3 B-2	(Component) A-5 B-2 A-4 A-3 B-4 A-5 A-4 B-4	* 3 3 -
Conductor         Componenth Side           Q501         B-5         B-1           Q502         B-4         Q503         B-4           Q504         B-2         Q506         B-5         B-1           Q505         B-2         Q506         B-5         B-1           Q508         B-5         B-1         Q508         B-2         Q-4           Q509         B-4         B-2         Q510         B-5         B-1         Q511         B-5         B-1         Q511         B-5         B-1         Q512         C-5         C-1         Q513         C-5         C-1         Q514         B-2         Q517         C-5         C-1         Q514         B-2         Q517         C-5         C-1         Q518         B-4         B-2         Q517         C-5         C-1         Q518         B-4         B-2         Q519         C-5         Q52         C-5         Q520         B-3         Q521         C-5         Q520         B-3         Q521         C-5         Q522         C-5         Q522         C-5         Q522         C-5         Q522         C-5         Q522         C-5         Q524         B-3         Q526         B-4         Q-2	*	D514 D515 D516 D517 D519 D520 D522 D701 D702 D708 D709 D710 D901 D901 D902 D904 D905 D906 D907 D908 D907 D908 D909 D911 D912 D911 D912 D911 D912 D913 D915 D917 D915 D917 D915 D917 D915 D917 D915 D917 D915 D917 D917 D918 D919 D917 D918 D919 D919 D919 D910 D915 D917 D918 D917 D918 D918 D919 D918 D919 D919 D919 D919	B-3 B-3 C-4 A-3 D-5 D-5 D-5 D-4 D-4 D-1 A-5 A-5 B-3 B-3 C-3 C-3 B-2 C-1 C-2 B-1 C-2 B-3	D-2 D-2 D-2 D-5 A-1 A-1 B-3 B-3 B-3 C-3 B-4 C-4 B-3 B-3 B-3 B-3 B-3 B-3 B-3 B-3 B-3 B-3	333 3
Q902 C-5 Q903 C-3 Q904 C-3 Q905 C-3 C-3 Q906 C-3 C-3 Q907 C-4 Q908 C-4 Q909 C-5 Q910 B-4		VAR	(Conductor Side B-1	(Component) B-5	DR -

\*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 5-12)








# NOTE:


The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.

Schematic diagram












# • A BOARD WAVEFORMS




## A BOARD IC401 M52757FP



# • A BOARD IC402 M52749FP









### NOT


The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.

Schematic diagram

A board









## - S BOARD (Conductor Side) -


G




5-25


## - S BOARD (Component Side) -






← S board






5-31


## - N BOARD (Conductor Side) -



#### N BOARD SEMICONDUCTOR LOCATION




- N BOARD (Component Side) -




\*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 5-12)

5-33





#### — G BOARD —



# G BOARD SEMICONDUCTOR LOCATION


	AIIO	••
	IC	
IC610 IC620 IC630 IC650 IC651 IC652 IC653 IC654 IC680	A-4 B-3 D-3 B-1 D-1 C-1 C-1 D-2	
TRA	NSIS <sup>-</sup>	TOR
Q610 Q611 Q612 Q613 Q620 Q621 Q630 Q631 Q632 Q633 Q652 Q653 Q653 Q667 Q671	D-2 A-4 A-4 A-3 A-3 C-3 D-3 D-3 C-1 C-1 C-1 D-1	* - 0 0 0 0 0 0 0
	DIODE	=
D601 D610 D613 D620 D630 D631 D632 D633 D635 D637 D640 D650 D651 D652 D653 D654 D655 D664 D680 D681 D682 D690	B-3 B-4 A-4 A-4 D-2 C-3 C-3 C-3 C-3 A-1 B-2 B-1 A-1 B-2 C-1 D-1 D-3 D-4	** 3

\*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 5-12)




The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.


5-37 5-38







#### (7) Schematic Diagrams of H and J Boards






# — H BOARD (Conductor Side) — — H BOARD (Component Side) — — J BOARD —







(H1)








(H2)

#### 5-5. SEMICONDUCTORS

BA00AST-V5 BA05ST-V5 LA6500FA



**BA033T** 



BA05T



BA10324AF-E2 SN74HC04ANS SN74HC04ANSR TC74VHCT74AFT XRA10324AF



BA9758FS-E2



BA9759F-E2



CXD8744Q



CXD9510Q



CXD9514M



**DM-57N** 



FA13842P



FA4301



HA17431PA HA17431PA-TZ



H8D2972



KC82C160SH



LA6510



LA6515 SDK391-220



LA7841L



LA7865M-TLM



MCZ3001D 27C4002-CPU118V



MM1170BFB M24C16-MN6T

NJM082M NJM2904M NJM2904M(TE2) ST24FC21M6TR TL082CPS-E20 24LC21AT/SN



8 pin SOP



#### MZ1530



M52749FP-TP



## M52757FP-TP





PQ3TZ53U



PST600J-T



SD102-V1



μPC2912HF(12)




DTA114EKA-T146 DTA114GKAT146 **DTA114TUA-T106 DTA124EUA-T106** DTA143TKA-T146 DTC114EK DTC114EKA-T146 DTC114GKA DTC114GKAT146 DTC123EKA-T146 DTC124EK DTC124EKA-T146 DTC124EUA-T106 2SA1036K-Q 2SA1036K-T-146-Q 2SA1037AK-T146-QR 2SA1037AK-T146-R 2SA1162-G 2SB709A-QRS-TX 2SC1623-L5L6 2SC2411K-CQ 2SC2411K-T-146-CQ 2SC2412K-T-146-QR



2SA1049-GR 2SA1049TP-GR 2SC2459-GR-TPE4



2SA1358-Y 2SC3421-Y




2SB1565EF 2SC3746 2SC5022-02 2SD2394-EF



2SC2362K-G 2SC2362KG-AA



2SC2784 2SC3311A-QRSTA




2SC3209LK 2SC3209LK-TP



2SC4015TV2



2SC4634LS-CB11



2SC5570(LBSONY)



2SJ360-TE12L



2SJ569LS-CB11 2SK2640-010MR 2SK2655-01R-F165 2SK3262-01MR-F119



DTZ-TT11-3.3B MA111 MA8039 RD2.2M-T1B RD5.6S-B UDZ-TE-17-2.2B UDZ-TE-17-3.3B UDZ-TE-17-3.9B UDZ-TE-17-5.6B 1SS355TE-17



D1NL20U-TR D2S4MF D2S4MTA1



D4SBL40 D4SBS4 D4SBS4-F D4SB60L



D5SC4M




EGP10D EGP10DPKG23 ERA91-02 ERA91-02TP1 1SS133T-77



ERA22-06AVRBT ERA22-08 ERA33-10TP1 ERB38-06V1 GP08D GP08DPKG23 HSS83TD RGP02-20EL-6394



FMQ-G5GS



**HSU83TRF** 



HZS12NB2TD HZS13NB2TD HZS16NB2TD HZS5.1NB2TD HZS5.6NB2TD HZS9.1NB2 MTZJ-T-77-39B MTZJ-39B RD10ESB2 RD12ES-B2 RD13ES-B2 RD13ES-T1B2 RD20ES-B2 RD20ES-T1B2 RD22ES-B2 RD22ES-T1B2 RD27ES-B2

HZS10NB2TD






MA151WK-TX 1SS184



PC123F2 PC123FY2



P6KE200AG23



RM11A RM11C



YG802C09



YG911S3R



1PS181-115



1PS226-115



1SS376TE-17



SPR-505MVWT31



# **SECTION 6 EXPLODED VIEWS**

- Items with no part number and no Items marked " \* " are not stocked since description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified  ${\mathbin{\mit \Delta}}$  marked are critical for safety.


Replace only with the part number specified.

Les composants identifiés par la marque  ${\mathbb A}$ sont critiques pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié.

## 6-1. CHASSIS

△: 7-685-881-09 +BVTT 4x8 : 7-685-648-79 +BVTP 3x12 ■: 7-685-663-71 +BVTP 4x16 



REF.I	NO. PART NO.	DESCRIPTION	REMARK	REF.NO	O. PART NO.	DESCRIPTION	REMARK
1	4-077-500-11	BEZEL		11	* 8-933-442-00	S BOARD, COMPLETE	
2		SCREW, TAPPING 7+CROW	/N WASHER	12		TERMINAL BOARD ASSY, I/O	)
3	*8-933-440-00	D BOARD, COMPLETE	4	13	4-070-122-01	SCREW (HD15)	
4	<b>△</b> 1-453-348-11	TRANSFORMER ASSY, FLY	BACK	14	* 8-933-432-00	A BOARD, COMPLETE	
			(NX-4504)	15	4-389-025-11	SCREW (M4) (EXT TOOTH W	ASHER)
5	4-062-115-01	SCREW +P 3.5X20 TYPE2					
				16	* 4-069-570-01	SPACER, PWB	
6	*8-933-441-00	G BOARD, COMPLETE		17	* 4-063-711-01	SUPPORT, HV CABLE	
7	* 3-701-903-11	HOLDER, PRINTED CIRCUI	T BOARD	18	X-4038-577-1	CABINET ASSY	
8	4-070-730-01	HOLDER, PWB		19	4-077-514-11	COVER, SCREW (L)	
9	₾ 1-251-382-31	INLET, AC 3P(WITH NOISE	FILTE)	20	4-077-515-11	COVER, SCREW (R)	
10	4-052-345-01	SCREW, (3X8) (+K), TAPPIN	G				
				21	4-077-512-11	COVER, ECS	
				22	* 4-080-891-01	LABEL, INFORMATION	


## 6-2. PICTURE TUBE

The components identified  ${\mathbin{f \vartriangle}}$  marked are critical for safety.
Replace only with the part number specified.

Les composants identifiés par la marque  ${\mathbb A}$ sont critiques pour la sécurité.


Ne les remplacer que par une pièce portant le numéro spécifié.

△: 7-685-881-09 +BVTT 4x8 ◆: 7-685-648-79 +BVTP 3x12



REF.	NO. PART NO.	DESCRIPTION	REMARK	REF.N	O. PART NO.	DESCRIPTION	REMARK
51 52		ITC ASSY (24TXF-R1) SPACER, DY	52-54	65	* 4-394-972-21	CAP, POWER	
53		NECK ASSY (NA-2917)		66	* 8-933-456-00	US BOARD, COMPLETE	
54	₾ 1-451-523-11	DEFLECTION YOKE (Y24TXN-	T)	67	4-072-376-01	COVER, STAND	
55	* 4-047-316-01	SPRING, EXTENSION		68	* 1-543-830-11	CLAMP, SLEEVE FERRITE	
				69	* 8-933-489-00	BLOCK ASSY, CONTROL (I	H BOARD)
56	₾ 1-419-675-11	COIL, ROTATION		70	4-041-021-02	HOLDER, DEGAUSE COIL	
57	₾ 1-419-673-11	COIL, DEGAUSSING					
58	₾ 1-419-674-11	COIL, LANDING CORRECTION	l	71	4-071-175-01	HOLDER, DGC	
59	* 8-933-433-00	N BOARD, COMPLETE		72	4-308-870-00	CLIP, LEAD WIRE	
60	4-070-730-01	HOLDER, PWB		73	1-452-032-00	MAGNET, DISK; 10mmφ	
				74	1-452-094-00	MAGNET, ROTATABLE DIS	SK; 15mmφ
61	* 4-321-929-00	HOLDER, PC BOARD		75	4-051-736-21	PIECE A(90), CONV. CORR	ECT
62	X-4038-576-1	STAND ASSY	63				
63	* 4-061-996-01	CUSHION		76	4-036-700-01	SHEET, PROTECTION	
64	* 8-933-396-00	J BOARD, COMPLETE		77	1-251-642-21	CAP ASSY,HIGH-VOLTAGE	

# 6-3. PACKING MATERIALS



REF.N	O. PART NO.	DESCRIPTION	REMARK	REF.NO. PART NO.	DESCRIPTION	REMARK
101	* 4-076-657-01	CUSHION (UPPER) (ASSY)				
102		CUSHION (LOWER) (ASSY)				
103	* 4-080-718-01	INDIVIDUAL CARTÓN				
104	* 4-030-594-11	BAG, PROTECTION				
105	* 4-396-077-01	JOINT				
106	* 4-077-239-01	TILT PAD				
107	* 4-055-439-01	TRAY				
108	4-080-892-11	MANUAL, INSTRUCTION				

# **SECTION 7 ELECTRICAL PARTS LIST**



#### NOTE:

The components identified △ marked are critical for safety.

Replace only with the part number specified.

Les composants identifiés par la marque ∆ sont critiques pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

The components identified by ■ in this • Items marked " \* " are not stocked since manual have been carefully factoryselected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

• All variable and adjustable resistors have • F : nonflammable characteristic curve B, unless otherwise noted.

they are seldom required for routine service. Some delay should be anticipated when ordering these items.

#### **RESISTORS**

- All resistors are in ohms

REF.NO.	PART NO.	DESCRIPTION		REM	ARK	REF.NO.	PART NO.	DESCRIPTION		REM	ARK
,	* 8-933-396-00	J BOARD, COM				C027 C028		CERAMIC CHIP CERAMIC CHIP		10.00% 0.25PF	50V 50V
	<connecto< td=""><td>)R&gt;</td><td></td><td></td><td></td><td>C029 C031</td><td>1-126-964-11</td><td></td><td>10UF</td><td>5.00% 20.00% 10.00%</td><td>50V 50V 50V</td></connecto<>	)R>				C029 C031	1-126-964-11		10UF	5.00% 20.00% 10.00%	50V 50V 50V
CN891	*1-691-960-11	PIN, CONNECT	OR (PC BC	ARD) 3P		C033 C036 C037		CERAMIC CHIP CERAMIC CHIP ELECT		10.00% 10.00% 20.00%	50V 50V 50V
	<switch></switch>					C038	1-126-964-11	-	10UF	20.00%	50V
S891 <u></u>	∆ 1-771-727-11	SWITCH, AC PC	WER PUS	Н		C040 C041	1-126-964-11 1-126-964-11 1-126-964-11	ELECT ELECT	10UF 10UF 10UF	20.00% 20.00% 20.00%	50V 50V 50V
								CERAMIC CHIP		10.00%	50V
		N BOARD, COM	IPLETE	******	****	C043 C044 C045 C046 C047	1-163-037-11 1-163-037-11	ELECT CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.022UF 0.022UF	20.00% 10.00% 10.00% 10.00% 10.00%	50V 50V 50V 50V 50V
	<capacitor< td=""><td>₹&gt;</td><td></td><td></td><td></td><td>C048 C049 C050</td><td>1-163-021-91 1-126-964-11 1-126-964-11</td><td></td><td>0.01UF 10UF 10UF</td><td>10.00% 20.00% 20.00%</td><td>50V 50V 50V</td></capacitor<>	₹>				C048 C049 C050	1-163-021-91 1-126-964-11 1-126-964-11		0.01UF 10UF 10UF	10.00% 20.00% 20.00%	50V 50V 50V
C001 C002 C003	1-163-009-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.001UF	10.00% 10.00% 10.00%	50V 50V 50V	C051		CERAMIC CHIP		10.00%	50V 16V
C005 C006	1-163-255-11	CERAMIC CHIP CERAMIC CHIP	150PF	5.00% 5.00%	50V 50V	C053 C054 C055		CERAMIC CHIP CERAMIC CHIP ELECT		10.00% 10.00% 20.00%	50V 50V 25V
C007 C008 C011	1-164-004-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.1UF	5.00% 10.00% 10.00%	50V 25V 50V	C056 C057	1-126-965-11 1-126-964-11	ELECT	22UF 10UF	20.00%	50V 50V
C012	1-126-967-11 1-126-965-11	ELECT	47UF 22UF	20.00%	50V 50V	C058 C059 C061	1-126-964-11	CERAMIC CHIP ELECT CERAMIC CHIP	10UF	5.00% 20.00% 10.00%	50V 50V 50V
C014 C015 C016	1-163-021-91	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01UF	10.00% 10.00% 10.00%	50V 50V 50V	C062 C063	1-104-665-11		100UF	20.00%	25V 50V
C017 C018	1-163-021-91	CERAMIC CHIP CERAMIC CHIP	0.01UF	10.00% 10.00%	50V 50V	C064 C065 C066	1-126-960-11	CERAMIC CHIP ELECT CERAMIC CHIP	1UF	5.00% 20.00% 5.00%	25V 50V 50V
C019 C020 C021	1-163-021-91	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01UF	10.00% 10.00% 10.00%	50V 50V 50V	C067 C068		CERAMIC CHIP		10.00% 5.00%	25V 50V
C022 C023	1-163-021-91	CERAMIC CHIP CERAMIC CHIP	0.01UF	10.00%	50V 50V	C069 C070 C071	1-126-767-11	CERAMIC CHIP ELECT CERAMIC CHIP	1000UF	10.00% 20.00% 10.00%	50V 16V 50V
C024 C025 C026		CERAMIC CHIP CERAMIC CHIP ELECT		10.00% 10.00% 20.00%	50V 50V 25V	C072	1-126-942-61		1000UF	20.00%	25V 50V



REF.NO.	PART NO.	DESCRIPTION		REM	ARK	REF.NO.	PART NO.	DESCRIPTION		REM	ARK
C074	1-163-137-00	CERAMIC CHIP	680PF	5.00%	50V	C5413	1-164-004-11	CERAMIC CHIP 0	.1UF	10.00%	25V
		CERAMIC CHIP		5.00%	50V		1-126-967-11			20.00%	50V
C077		CERAMIC CHIP		10.00%	50V			CERAMIC CHIP 0		10.00%	50V
C078 C079	1-136-169-00 1-163-021-91	MYLAR CERAMIC CHIP	0.22UF 0.01UF	5.00% 10.00%	50V 50V	C5606	1-163-021-91	CERAMIC CHIP 0	0.01UF	10.00%	50V
C080	1-126-967-11	ELECT	47UF	20.00%	50V	C5607	1-164-004-11	CERAMIC CHIP 0	).1UF	10.00%	25V
C082	1-104-664-11		47UF	20.00%	25V						
C083		CERAMIC CHIP		10.00%	50V		<connecto< td=""><td>R&gt;</td><td></td><td></td><td></td></connecto<>	R>			
C084 C085	1-126-964-11	ELECT CERAMIC CHIP	10UF	20.00%	50V	CNIOO4	4 704 500 44	CONNECTOR FE	-C/EDC 041	_	
				10.00%	50V	CN002 <sup>3</sup>	*1-564-511-11	CONNECTOR, FF PLUG, CONNECT	OR 8P		
C086		CERAMIC CHIP	0.01UF 10UF	10.00%	50V			CONNECTOR, FF			
C087 C089	1-126-964-11	CERAMIC CHIP		20.00% 10.00%	50V 50V			CONNECTOR, FF		-	
C090		CERAMIC CHIP		10.00%	50V	CINOTO	1-704-700-11	CONNECTOR, IT	0 231		
C091	1-126-933-11		100UF	20.00%	16V	CN011	1-784-786-11	CONNECTOR, FF	C 25P		
								1 PLUG, CONNEC			
C093		CERAMIC CHIP		10.00%	50V			1 PLUG, CONNEC			
C094		CERAMIC CHIP		10.00%	25V	CN5003	3* 1-564-505-1	1 PLUG, CONNEC	CTOR 2P		
C095 C096	1-117-722-11	CERAMIC CHIP	2200UF	20.00% 10.00%	10V 50V						
C097	1-126-964-11		10UF	20.00%	50V		<diode></diode>				
C098	1-115-330-11	CERAMIC CHIP	0.1LIE	10.00%	50V	D001	9 710 062 51	DIODE 1PS226-1	15		
		CERAMIC CHIP		10.00%	25V			DIODE 1PS226-1			
	1-104-664-11		47UF	20.00%	25V			DIODE 1PS226-1			
C1004	1-115-339-11	CERAMIC CHIP	0.1UF	10.00%	50V	D004	8-719-062-51	DIODE 1PS226-1	15		
C1005	1-163-005-11	CERAMIC CHIP	470PF	10.00%	50V	D008	8-719-109-89	ZENER DIODE RI	D5.6ESB2		
		CERAMIC CHIP			50V			ZENER DIODE RI			
		CERAMIC CHIP		0.25PF	50V			ZENER DIODE RI			
	1-163-087-00	CERAMIC CHIP	10UF	0.25PF 20.00%	50V 50V			ZENER DIODE RI ZENER DIODE RI			
	1-126-933-11		100UF	20.00%	16V			DIODE 1SS184	DIOLOBZ		
	1-104-664-11		47UF	20.00%	25V	D016	8-719-109-89	ZENER DIODE RI	D5.6ESB2		
	1-104-664-11		47UF	20.00%	25V			ZENER DIODE RI			
	1-104-664-11	CERAMIC CHIP	47UF	20.00% 10.00%	25V 25V			ZENER DIODE RI			
		CERAMIC CHIP		10.00%	25V 25V	D020 D021		DIODE 1SS355TE			
		CERAMIC CHIP		10.00%	25V			DIODE 1SS184			
	1-104-664-11		47UF	20.00%	25V 25V			DIODE 155184			
		CERAMIC CHIP		10.00%	25V			DIODE 1SS184			
		CERAMIC CHIP		10.00%	25V	D025		DIODE 1PS226-1	15		
C5110	1-104-664-11	ELECT	47UF	20.00%	25V	D026	8-719-062-51	DIODE 1PS226-1	15		
		CERAMIC CHIP		10.00%	25V	D027	8-719-988-61	DIODE 1SS355TE	-17		
		CERAMIC CHIP		10.00%	25V			DIODE 1SS355TE			
		CERAMIC CHIP		10.00%	50V			ZENER DIODE RI			
		CERAMIC CHIP		10.00% 10.00%	25V 25V	D036 D037		ZENER DIODE RI			
C5304	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V	D038	8-719-045-99	ZENER DIODE RI	D2.2M-T1B	<b>.</b>	
C5305	1-104-664-11	ELECT	47UF	20.00%	25V						
		CERAMIC CHIP		10.00%	25V						
		CERAMIC CHIP		10.00%	25V		<ferrite be<="" td=""><td>EAD&gt;</td><td></td><td></td><td></td></ferrite>	EAD>			
C5310	1-104-664-11	ELECT	47UF	20.00%	25V	EB004	1-410-397-21	EEDDITE 1	.1UH		
C5401	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V		1-410-397-21		.1UH .1UH		
		CERAMIC CHIP		10.00%	50V		1-410-397-21		.1UH		
		CERAMIC CHIP		10.00%	50V		11-412-911-11		.1UH		
		CERAMIC CHIP		10.00%	25V	FB5103	31-412-911-11	FERRITE 1	.1UH		
C5408	1-163-005-11	CERAMIC CHIP	470PF	10.00%	50V	FDFSS	14 440 0 : : : :	FEDDITE	41.02		
C5409	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V		1-412-911-11   1-412-911-11		.1UH .1UH		



REF.NO.	PART NO.	DESCRIPTION	N	REMARK	REF.NO.	PART NO.	DESCRIPTION	ı	R	EMARK
FB5401	31-412-911-11   1-412-911-11   31-412-911-11	FERRITE	1.1UH 1.1UH 1.1UH		R016 R017 R018	1-216-017-91 1-216-017-91 1-216-049-91	RES-CHIP	47 47 1K	5% 5% 5%	1/10W 1/10W 1/10W
FB560 <sup>2</sup>	11-412-911-11	FERRITE	1.1UH		R019 R020	1-216-025-91 1-216-025-91		100 100	5% 5%	1/10W 1/10W
	<sensor></sensor>				R021 R022 R023	1-216-025-91 1-216-025-91	RES-CHIP	100 100 4.7K	5%	1/10W 1/10W 1/10W
GS500	1 1-418-473-1	I1 SENSOR UNI	T, GEOWAGN	ETIC	R023 R024 R025	1-216-065-91 1-216-025-91 1-216-025-91	RES-CHIP	100 100	5% 5% 5%	1/10W 1/10W 1/10W
	<ic></ic>				R026 R029	1-216-025-91 1-216-073-00		100 10K	5% 5%	1/10W 1/10W
IC002 IC003	8-759-162-80 8-759-527-77	IC CXD-8744Q- IC MM1170BFE IC M24C16-MN	8 6T		R030 R031 R032	1-216-049-91 1-216-669-11 1-216-665-11	METAL CHIP	1K 5.6K 3.9K	0.50%	1/10W 61/10W 61/10W
IC005	8-759-491-55	IC TC74VHCT7	` '		R034 R035	1-216-049-91 1-216-073-00	RES-CHIP	1K 10K	5%	1/10W 1/10W
IC010 IC011	8-759-585-70	IC NJM082M IC LA7865M-TL IC ST24FC21M IC LA6510			R036 R037 R039	1-216-659-11 1-216-073-00 1-216-025-91		2.2K 10K 100		51/10W 1/10W 1/10W
IC5301	8-759-822-07 8-759-822-38 8-759-822-07	IC LA6510			R040 R042 R043 R044	1-216-025-91 1-216-073-00 1-216-049-91	RES-CHIP	100 10K 1K 1.8K	5%	1/10W 1/10W 1/10W 51/10W
105401		IC LA0515			R045	1-216-049-91	RES-CHIP	1K	5%	1/10W
L002	<coil> 1-406-665-11</coil>	INDUCTOR 100	DUH		R046 R047 R048	1-216-073-00 1-216-049-91 1-216-049-91	RES-CHIP	10K 1K 1K	5% 5% 5%	1/10W 1/10W 1/10W
L003	1-406-671-11	INDUCTOR 1M	Н		R049 R053	1-216-073-00 1-216-065-91		10K 4.7K	5% 5%	1/10W 1/10W
0001	<transisto< td=""><td>OR&gt; TRANSISTOR 2</td><td>00 A 4007 A 1/ T4</td><td>146 D</td><td>R054 R055</td><td>1-216-077-91 1-216-077-91</td><td>RES-CHIP</td><td>15K 15K</td><td></td><td>1/10W 1/10W</td></transisto<>	OR> TRANSISTOR 2	00 A 4007 A 1/ T4	146 D	R054 R055	1-216-077-91 1-216-077-91	RES-CHIP	15K 15K		1/10W 1/10W
Q001 Q002 Q003 Q004	8-729-026-49 8-729-026-49	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 1	2SA1037AK-T1 2SA1037AK-T1	146-R 146-R	R056 R057 R058	1-216-073-00 1-216-073-00 1-216-067-00	RES-CHIP RES-CHIP	10K 10K 5.6K	5% 5% 5%	1/10W 1/10W 1/10W
		TRANSISTOR I			R059 R060 R061	1-216-057-00 1-216-057-00 1-216-049-91	RES-CHIP	2.2K 2.2K 1K		1/10W 1/10W 1/10W
Q007 Q008 Q009	8-729-901-00 8-729-033-25 8-729-120-28	TRANSISTOR I TRANSISTOR I TRANSISTOR 2	DTC124EK DTC114GKA 2SC1623-L5L6		R062 R063	1-216-613-11	METAL CHIP METAL CHIP	27 27	0.50% 0.50%	61/10W 61/10W
Q010 Q011 Q012	8-729-026-49	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR I	2SA1037AK-T1		R064 R066 R067 R068 R069	1-216-613-11 1-216-049-91 1-216-073-00 1-216-295-91 1-216-295-91	RES-CHIP SHORT	27 1K 10K 0		51/10W 1/10W 1/10W
	<resistor:< td=""><td>&gt;</td><td></td><td></td><td>R070 R071</td><td>1-216-295-91 1-216-295-91</td><td>SHORT</td><td>0</td><td></td><td></td></resistor:<>	>			R070 R071	1-216-295-91 1-216-295-91	SHORT	0		
R003 R004 R005 R006	1-216-025-91 1-216-025-91 1-216-025-91 1-216-025-91	RES-CHIP RES-CHIP	100 5° 100 5°	% 1/10W % 1/10W % 1/10W % 1/10W	R072 R073 R074	1-216-295-91 1-216-295-91 1-216-295-91	SHORT	0 0 0		
R007	1-216-057-00 1-216-057-00	RES-CHIP	2.2K 5°	% 1/10W % 1/10W % 1/10W	R075 R076 R078	1-215-407-00 1-215-407-00 1-216-121-91	METAL	270 270 1M	1% 1% 5%	1/4W 1/4W 1/10W
R009 R010	1-216-057-00 1-216-057-00	RES-CHIP RES-CHIP	2.2K 5° 2.2K 5°	% 1/10W % 1/10W	R078 R079 R080	1-216-295-91 1-216-295-91	SHORT	0	J /0	1/1000
R014 R015	1-216-049-91 1-249-389-11			% 1/10W % 1/4W	R081	1-216-049-91	RES-CHIP	1K	5%	1/10W

# **GDM-FW9011**



REF.NO.	PART NO.	DESCRIPTION		RI	EMARK	REF.NO.	PART NO.	DESCRIPTION		R	EMARK
R082	1-216-049-91	RES-CHIP	1K	5%	1/10W	R1043	1-216-025-91	RES-CHIP	100	5%	1/10W
R084	1-216-073-00		10K	5%	1/10W		1-216-667-11		4.7K		61/10W
	1-216-049-91		1K		1/10W		1-216-065-91		4.7K	5%	1/10W
	1-216-049-91		1K	5%	1/10W	111040	1 210 000 01	INEO OF III	7.710	070	1/1000
11000	1-210-043-31	INEO-OI III	IIX	J /0	1/1000	D1046	1-216-025-91	DEC CHID	100	5%	1/10W
DOOO	1 216 072 00	DEC CLUD	101/	E0/	1/10\\					5% 5%	
	1-216-073-00		10K	5%	1/10W		1-216-073-00		10K		1/10W
R091	1-216-049-91		1K	5%	1/10W		1-216-065-91		4.7K	5%	1/10W
	1-216-049-91		1K	5%	1/10W		1-216-073-00		10K	5%	1/10W
	1-216-049-91		1K	5%	1/10W	R1051	1-216-097-91	RES-CHIP	100K	5%	1/10W
R094	1-216-049-91	RES-CHIP	1K	5%	1/10W						
						R1052	1-216-073-00	RES-CHIP	10K	5%	1/10W
R095	1-216-049-91	RES-CHIP	1K	5%	1/10W	R1053	1-216-049-91	RES-CHIP	1K	5%	1/10W
R096	1-216-065-91	RES-CHIP	4.7K	5%	1/10W	R1054	1-216-073-00	RES-CHIP	10K	5%	1/10W
R097	1-216-073-00	RES-CHIP	10K	5%	1/10W	R1055	1-216-049-91	RES-CHIP	1K	5%	1/10W
R098	1-216-073-00	RES-CHIP	10K	5%	1/10W	R1056	1-216-073-00	RES-CHIP	10K	5%	1/10W
	1-216-049-91		1K	5%	1/10W						
11000	1 210 010 01	1120 01111		070	1, 1011	R1057	1-216-049-91	RES-CHIP	1K	5%	1/10W
D1001	1-216-049-91	DEC CHID	1K	5%	1/10W		1-216-073-00		10K	5%	1/10W
	1-216-049-91		1K	5%	1/10W		1-216-049-91		1K	5%	1/10W
	1-216-049-91		1K	5%	1/10W		1-216-073-00		10K	5%	1/10W
	1-216-049-91		1K		1/10W	R1061	1-216-073-00	RES-CHIP	10K	5%	1/10W
R1005	1-216-049-91	RES-CHIP	1K	5%	1/10W						
							1-216-049-91		1K	5%	1/10W
R1006	1-216-049-91	RES-CHIP	1K	5%	1/10W	R1063	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R1007	1-216-049-91	RES-CHIP	1K	5%	1/10W	R1064	1-216-049-91	RES-CHIP	1K	5%	1/10W
R1008	1-216-667-11	METAL CHIP	4.7K	0.50%	61/10W	R1065	1-216-117-00	RES-CHIP	680K	5%	1/10W
R1009	1-216-049-91	RES-CHIP	1K	5%	1/10W	R1066	1-216-073-00	RES-CHIP	10K	5%	1/10W
R1010	1-216-049-91	RES-CHIP	1K	5%	1/10W						
				0,0	.,	R1067	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R1011	1-216-049-91	RES-CHIP	1K	5%	1/10W		1-216-065-91		4.7K	5%	1/10W
	1-216-057-00		2.2K	5%	1/10W		1-216-049-91		1K	5%	1/10W
			2.2K 2.2K								
	1-216-057-00			5%	1/10W		1-216-057-00		2.2K	5%	1/10W
	1-216-049-91		1K	5%	1/10W	K10/1	1-216-081-00	RES-CHIP	22K	5%	1/10W
R1015	1-216-049-91	RES-CHIP	1K	5%	1/10W	<b>5</b>		01100=	_		
							1-216-295-91		0		
	1-216-049-91		1K	5%	1/10W		1-216-295-91		0		
R1017	1-216-049-91	RES-CHIP	1K	5%	1/10W	R1077	1-216-025-91	RES-CHIP	100	5%	1/10W
R1018	1-216-049-91	RES-CHIP	1K	5%	1/10W	R5003	1-216-295-91	SHORT	0		
R1019	1-216-049-91	RES-CHIP	1K	5%	1/10W	R5005	1-216-081-00	RES-CHIP	22K	5%	1/10W
R1020	1-216-065-91	RES-CHIP	4.7K	5%	1/10W						
						R5006	1-216-073-00	RES-CHIP	10K	5%	1/10W
R1021	1-216-065-91	RES-CHIP	4.7K	5%	1/10W	R5007	1-216-049-91	RES-CHIP	1K	5%	1/10W
	1-216-659-11		2.2K		61/10W		1-216-295-91		0		
	1-216-659-11	_	2.2K		61/10W		1-216-073-00		10K	5%	1/10W
	1-216-681-11	•	18K		61/10W		1-216-049-91		1K	5%	1/10W
	1-216-025-91		100		1/10W	11.0010	1 210 043 31	INEO-OF III	110	370	1/1000
K1025	1-210-025-91	KL3-CHIF	100	3 /0	1/1000	DE100	1-216-308-00	DEC CLUD	4.7	E0/	1/10W
D4006	1 016 100 00	DEC CLUD	2201/	E0/	1/10\\				4.7	5% 5%	
	1-216-109-00		330K		1/10W		1-216-308-00		4.7	5%	1/10W
	1-216-659-11	_	2.2K		61/10W		1-216-073-00		10K	5%	1/10W
	1-216-647-11		680		61/10W		1-216-073-00		10K	5%	1/10W
	1-216-025-91		100		1/10W	R5115	1-215-859-00	METAL OXIDE	22	5%	1W
R1030	1-216-025-91	RES-CHIP	100	5%	1/10W						
						R5116	1-216-073-00	RES-CHIP	10K	5%	1/10W
R1031	1-216-025-91	RES-CHIP	100	5%	1/10W	R5119	1-216-073-00	RES-CHIP	10K	5%	1/10W
R1032	1-216-025-91	RES-CHIP	100	5%	1/10W	R5122	1-215-859-00	METAL OXIDE	22	5%	1W
R1033	1-216-025-91	RES-CHIP	100	5%	1/10W	R5205	1-216-073-00	RES-CHIP	10K	5%	1/10W
	1-216-025-91		100	5%	1/10W			METAL OXIDE		5%	1W
	1-216-025-91		100		1/10W	110200				070	
11.000				2 / 0	.,	R5207	1-216-073-00	RES-CHIP	10K	5%	1/10W
R1036	1-216-025-91	RES-CHID	100	5%	1/10W		1-216-069-00		6.8K	5%	1/10W
	1-216-025-91		100	5%	1/10W		1-216-308-00		4.7	5%	1/10W
	1-216-025-91		100	5%	1/10W		1-216-308-00		4.7	5%	1/10W
	1-216-025-91		100	5%	1/10W	K5309	1-216-308-00	KES-CHIP	4.7	5%	1/10W
K1040	1-216-025-91	RES-CHIP	100	5%	1/10W	_					
							1-216-073-00		10K	5%	1/10W
	1-216-025-91		100	5%	1/10W		1-216-073-00		10K	5%	1/10W
R1042	1-216-025-91	RES-CHIP	100	5%	1/10W	R5315	1-215-859-00	METAL OXIDE	22	5%	1W
						ı					



REF.NO.	PART NO.	DESCRIPTION		R	REMARK	REF.NO.	PART NO.	DESCRIPTION		REM	ARK
DE216	1-216-073-00	DEC CUID	10K	5%	1/10W	C2011	1 162 021 01	CERAMIC CHIP	0.041.15	10.00%	50V
R5319	1-216-073-00	RES-CHIP	10K	5%	1/10W			CERAMIC CHIP		10.00%	50V
D.F.0.00	4 045 050 00	METAL OVIDE	00	<b>5</b> 0/	4147			CERAMIC CHIP		10.00%	50V
		METAL OXIDE	22	5%	1W			CERAMIC CHIP		10.00%	50V
	1-216-083-00		27K	5%	1/10W	C3015	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
	1-216-085-00		33K	5%	1/10W						
R5408	1-216-308-00	RES-CHIP	4.7	5%	1/10W			CERAMIC CHIP		10.00%	50V
R5409	1-216-308-00	RES-CHIP	4.7	5%	1/10W	C3017	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
						C3018	1-163-021-91	<b>CERAMIC CHIP</b>	0.01UF	10.00%	50V
R5410	1-216-081-00	RES-CHIP	22K	5%	1/10W	C3019	1-164-004-11	<b>CERAMIC CHIP</b>	0.1UF	10.00%	50V
R5413	1-216-097-91	RES-CHIP	100K	5%	1/10W	C3020	1-126-964-11	FLECT	10UF	20.00%	50V
		METAL OXIDE	150	5%	2W	00020	0 00			20.0070	
	1-216-081-00		22K	5%	1/10W	C3021	1-164-004-11	CERAMIC CHIP	0 11 IF	10.00%	50V
	1-216-097-91		100K	5%	1/10W		1-126-960-11		1UF	20.00%	50V
113413	1-210-031-31	INLO-CI III	1001	J /0	17 10 0 0		1-126-964-11		10UF	20.00%	50V
DE 400	4 040 454 44	METAL OVIDE	100	<b>F</b> 0/	0)///						
		METAL OXIDE		5%	2W			CERAMIC CHIP		10.00%	50V
	1-216-081-00		22K	5%	1/10W	C3025	1-126-960-11	ELECT	1UF	20.00%	50V
	1-216-081-00		22K	5%	1/10W	_					
R5504	1-216-089-91	RES-CHIP	47K	5%	1/10W	C3026	1-126-964-11	ELECT	10UF	20.00%	50V
R5505	1-216-089-91	RES-CHIP	47K	5%	1/10W	C3027	1-126-964-11	ELECT	10UF	20.00%	50V
						C3028	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
R5506	1-216-069-00	RES-CHIP	6.8K	5%	1/10W	C3029	1-163-021-91	<b>CERAMIC CHIP</b>	0.01UF	10.00%	50V
R5507	1-249-382-11	CARBON	1.2	5%	1/4W	C3030	1-126-964-11	FLECT	10UF	20.00%	50V
	1-249-382-11	-	1.2	5%	1/4W		0 00			20.0070	
	1-249-382-11		1.2	5%	1/4W	C3031	1-164-004-11	CERAMIC CHIP	0 1LIF	10.00%	50V
	1-249-382-11		1.2	5%	1/4W			CERAMIC CHIP		10.00%	50V
K3510	1-249-302-11	CARBON	1.2	5%	1/400			CERAMIC CHIP			
D.F.0.00	4 040 004 00	DE0 01 11D	001/	<b>5</b> 0/	4 /4 014 /					10.00%	50V
	1-216-081-00		22K	5%	1/10W			CERAMIC CHIP		10.00%	50V
	1-216-077-91		15K	5%	1/10W	C3035	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
	1-216-081-00		22K	5%	1/10W						
R5605	1-216-097-91	RES-CHIP	100K	5%	1/10W	C3036	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
R5607	1-215-862-11	METAL OXIDE	68	5%	1W	C3037	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
						C3038	1-163-021-91	<b>CERAMIC CHIP</b>	0.01UF	10.00%	50V
R5610	1-216-308-00	RES-CHIP	4.7	5%	1/10W	C3039	1-163-021-91	<b>CERAMIC CHIP</b>	0.01UF	10.00%	50V
								CERAMIC CHIP		10.00%	50V
						000.0		02.0.000	0.0.0.	. 0.00 / 0	
	<crystal></crystal>					C3041	1-163-021-91	CERAMIC CHIP	0.01LIF	10.00%	50V
	CONTOTAL							CERAMIC CHIP		10.00%	50V
V004	1 700 000 01	VIDDATOD CD	VCTAL (04	ZECNII	I-\						
X001	1-760-662-21	VIBRATOR, CR	151AL (24.	. / SOIVIE	72)			CERAMIC CHIP		10.00%	50V
								CERAMIC CHIP		10.00%	50V
						C3045	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
						_					
********	******	******	*****	******	*******		1-126-965-11	_	22UF	20.00%	50V
								CERAMIC CHIP		10.00%	50V
						C3048	1-126-964-11	ELECT	10UF	20.00%	50V
*	8-933-442-00	S BOARD, COM	IPLETE			C3050	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	50V
		******	*****			C3052	1-126-963-11	ELECT	4.7UF	20.00%	50V
						C3053	1-163-005-11	CERAMIC CHIP	470UF	10.00%	50V
	4-077-446-01	HEAT SINK (S1)	(103002 1	C3003	)			CERAMIC CHIP		10.00%	50V
*		SPRING (F) (IC3			,		1-126-964-11		10UF	20.00%	50V
	4-301-900-01	SEKING (F) (ICC	0002, 10300	)3)				CERAMIC CHIP		10.00%	
											25V
	0.0.0.0.0.0					C3062	1-126-942-61	ELECT	1000UF	20.00%	25V
	<capacitor< td=""><td><b>&lt;&gt;</b></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></capacitor<>	<b>&lt;&gt;</b>									
							1-126-942-61		1000UF	20.00%	25V
C3001	1-163-021-91	CERAMIC CHIP	0.01UF	10.00	)% 50V	C3064	1-163-235-11	CERAMIC CHIP	22PF	5.00%	50V
C3002	1-163-021-91	CERAMIC CHIP	0.01UF	10.00	)% 50V	C3065	1-137-378-11	MYLAR	0.22UF	5.00%	50V
C3003	1-163-021-91	CERAMIC CHIP	0.01UF	10.00	)% 50V	C3066	1-163-235-11	CERAMIC CHIP	22PF	5.00%	50V
C3004	1-163-021-91	<b>CERAMIC CHIP</b>	0.01UF	10.00	)% 50V	C3067	1-137-378-11	MYLAR	0.22UF	5.00%	50V
C3005	1-164-004-11	<b>CERAMIC CHIP</b>	0.1UF	10.00	)% 50V						
						C3068	1-163-235-11	CERAMIC CHIP	22PF	5.00%	50V
C3006	1-126-964-11	FLECT	10UF	20.00	)% 50V		1-137-378-11		0.22UF	5.00%	50V
		CERAMIC CHIP		10.00				CERAMIC CHIP		5.00%	50V
		CERAMIC CHIP		10.00			1-137-378-11		0.22UF	5.00%	50V
		CERAMIC CHIP		10.00		U3072	1-107-823-11	CERAMIC CHIP	U.4/UF	10.00%	16V
C3010	1-163-021-91	CERAMIC CHIP	0.01UF	10.00	)% 50V	000-	4 400 001 71	OED 4440 0: ::=	0.041.1=	40.000	F0' '
						C3074	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V



REF.NO.	PART NO.	DESCRIPTION		REI	MARK	REF.NO.	PART NO.	DESCRIPTION		R	EMARK
C2075	1 164 004 44	CEDAMIC CLUE	0.04115	10.000/	251	D2040	1 216 065 04	DEC CLUD	4 7K	E0/	1/10W
		CERAMIC CHIP		10.00%			1-216-065-91 1-216-295-91		4.7K	5%	1/1000
		CERAMIC CHIP		10.00%			1-216-295-91		0 100	E0/	1/10W
		CERAMIC CHIP		10.00%		K3020	1-216-025-91	KES-CHIP	100	5%	1/1000
C3079	1-164-004-11	CERAIVIIC CHIP	0.106	10.00%	25 V	D2021	1-216-065-91	DES CHID	4.7K	5%	1/10W
C3080	1-16/-00/-11	CERAMIC CHIP	0 1 I I E	10.00%	25V		1-216-065-91		4.7K 4.7K	5%	1/10W
		CERAMIC CHIP		10.0070	10V		1-216-049-91		1K	5%	1/10W
		CERAMIC CHIP		10.00%			1-216-057-00		2.2K	5%	1/10W
00002	1 104 004 11	OLIV WIIO OTIII	0.101	10.0070	20 V		1-216-049-91		1K	5%	1/10W
						1.0020				0,0	.,
	<connecto< td=""><td>DR&gt;</td><td></td><td></td><td></td><td>R3026</td><td>1-216-057-00</td><td>RES-CHIP</td><td>2.2K</td><td>5%</td><td>1/10W</td></connecto<>	DR>				R3026	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
						R3027	1-216-049-91	RES-CHIP	1K	5%	1/10W
CN300	1 1-784-451-1	1 CONNECTOR	, FFC/FPC	9P		R3028	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
		1 PLUG, CONNI					1-216-025-91		100	5%	1/10W
CN3003	3* 1-564-518-1	1 PLUG, CONNI	ECTOR 3P			R3030	1-216-627-11	METAL CHIP	100	0.50%	61/10W
							1-216-667-11		4.7K		61/10W
	<diode></diode>						1-216-677-11		12K		61/10W
							1-216-666-11		4.3K		61/10W
		ZENER DIODE					1-216-667-11	_	4.7K		61/10W
		ZENER DIODE		3.3B		R3036	1-216-029-00	RES-CHIP	150	5%	1/10W
		DIODE MA111-						550 01115			
D3006	8-719-073-01	DIODE MA111-	(K8).SO				1-216-029-00		150		1/10W
							1-216-667-11		4.7K		61/10W
	10						1-216-667-11		4.7K	0.50%	61/10W
	<ic></ic>						1-216-295-91		0	0.500	(4/40)
102001	0 750 506 10	IC CXD9510Q				K3042	1-216-667-11	METAL CHIP	4.7K	0.50%	61/10W
		IC STK391-220				B3044	1-216-667-11	METAL CHIP	4.7K	0.50%	61/10W
		IC STK391-220					1-216-065-91		4.7K 4.7K	5%	1/10W
	8-759-445-59						1-216-003-91		10K	5%	1/10W
		IC M24C16-MN6	ST(A)					METAL OXIDE		5%	3W
103003	0 700 000 00	10 10124010 101140	) i (/\)					METAL OXIDE		5%	3W
IC3006	8-759-352-91	IC PST9143NL				110040	1 210 007 11	WE I'VE OVIDE	0.00	070	011
						R3049	1-216-667-11	METAL CHIP	4.7K	0.50%	61/10W
								METAL OXIDE		5%	3W
	<transisto< td=""><td>OR&gt;</td><td></td><td></td><td></td><td></td><td>1-216-667-11</td><td></td><td>4.7K</td><td>0.50%</td><td>61/10W</td></transisto<>	OR>					1-216-667-11		4.7K	0.50%	61/10W
						R3052	1-216-475-11	METAL OXIDE	120	5%	3W
Q3001	8-729-026-49	TRANSISTOR 2	SA1037AK	-T146-R		R3053	1-216-386-11	METAL OXIDE	0.56	5%	3W
Q3002	8-729-120-28	TRANSISTOR 2	SC1623-L5	5L6							
		TRANSISTOR 2				R3054	1-216-387-11	METAL OXIDE		5%	3W
		TRANSISTOR 2						METAL CHIP	4.7K		61/10W
Q3005	8-729-120-28	TRANSISTOR 2	SC1623-L5	SL6				METAL OXIDE		5%	3W
							1-216-667-11	_	4.7K		61/10W
						R3058	1-216-475-11	METAL OXIDE	120	5%	3W
	<resistor></resistor>	>				D0050	4 040 005 04	CUCRT			
D0004	4 040 004 44	METAL OLUB	450	0.500/4	(4.0) 4.1		1-216-295-91		0		
		METAL CHIP	150	0.50%1			1-216-295-91		0		
		METAL CHIP	4.7K	0.50%1			1-216-295-91		0		
		METAL CHIP	1K	0.50%1			1-216-295-91		0		
		METAL CHIP	2.7K	0.50%1 0.50%1		R3064	1-216-295-91	SHURT	0		
K3003	1-210-051-11	METAL CHIP	1K	0.50%1	/1000	D2065	1-216-627-11	METAL CHID	100	0.50%	61/10W
P3006	1-216-651-11	METAL CHIP	1K	0.50%1	/10\//			METAL OXIDE		5%	1W
		METAL CHIP	150	0.50%1				METAL OXIDE		5%	1W
		METAL CHIP	4.7K	0.50%1			1-216-097-91	_	100K	5%	1/10W
		METAL CHIP	1K	0.50%1			1-216-037-91		10K	5%	1/10W
		METAL CHIP	2.7K	0.50%1		1.0071	. 210-073-00	LO OI III	1011	J /0	1, 10 4 4
1.0010	0 001 11			0.00 /0 1		R3072	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R3011	1-216-651-11	METAL CHIP	1K	0.50%1	/10W		1-216-049-91		1K	5%	1/10W
		METAL CHIP	1K	0.50%1			1-216-077-91		15K	5%	1/10W
	1-216-057-00		2.2K		/10W		1-216-069-00		6.8K	5%	1/10W
	1-216-073-00		10K		/10W		1-216-069-00		6.8K	5%	1/10W
	1-216-065-91		4.7K		/10W		2 2 2 3 3 0	- +			
						R3077	1-216-073-00	RES-CHIP	10K	5%	1/10W
R3016	1-216-295-91	SHORT	0								
R3017	1-216-025-91	RES-CHIP	100	5% 1	/10W						
						I .					



REF.NO.	PART NO.	DESCRIPTION		REI	MARK	REF.NO.	PART NO.	DESCRIPTION		REM	MARK
	1-216-073-00 1-216-073-00		10K 10K		/10W /10W	C536 C537 C538 C539 C540		FILM CERAMIC CHIP CERAMIC CHIP		20.00% 5.00% 10.00% 10.00%	50V 250V 50V 50V 200V
******	******	*******	******	******	******						
						C541 C542		CERAMIC CHIP		10.00% 10.00%	50V 50V
*	*8-933-440-00	D BOARD, COM				C543	1-135-350-11	FILM	3600PF	3%	1.8KV
		******	*****			C544 C545	1-117-953-11 1-107-597-11		0.033UF 22PF	5.00% 5.00%	400V 500V
		COVER, VOLUN			)	C546	1-107-444-11		100PF	5.00%	2KV
		INSULATING SHINSULATING SH	,	,		C547 C548	1-130-061-91 1-162-134-11		0.0015UF 470PF	5.00%	630V 2KV
	4-070-830-01	INSULATING SH	HEET (IC70	1)	• •	C549	1-130-495-00		0.1UF	5.00%	50V
	4-077-445-01	HEAT SINK (D5)	) (R918, Q9	05, Q906	5)	C550	1-137-711-61	FILM	0.065UF	5.00%	50V
	4-382-854-11	SCREW (M3X10				C551		CERAMIC CHIP		10.00%	50V
	7-685-647-79	Q705, Q901, Q9 SCREW +BVTP				C552 C554	1-163-021-91	CERAMIC CHIP CERAMIC	0.01UF 100PF	10.00% 5.00%	50V 2KV
		(IC502, Q508, Q				C555	1-107-683-11		2.2UF		250V
						C556	1-117-892-11	FILM	2UF	5.00%	250V
	<capacitof< td=""><td>₹&gt;</td><td></td><td></td><td></td><td>C557</td><td></td><td>CERAMIC CHIP</td><td></td><td>10.00%</td><td>50V</td></capacitof<>	₹>				C557		CERAMIC CHIP		10.00%	50V
C501	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V	C558 C559	1-104-665-11 1-107-649-11	_	100UF 2.2UF	20.00% 20.00%	25V 250V
C502	1-136-169-00	MYLAR	0.22UF	5.00%	50V	C560	1-163-021-91	CERAMIC CHIP		10.00%	50V
C503 C504		CERAMIC CHIP		10.00% 10.00%		C561	1-104-664-11	ELECT	47UF	20.00%	25V
C505		CERAMIC CHIP		10.00%		C562		CERAMIC CHIP		10.00%	50V
C506	1-137-194-81	MYI AR	0.47UF	5.00%	50V	C564 C565	1-126-960-11 1-164-004-11	CERAMIC CHIP	1UF 0.1UF	20.00% 10.00%	50V 25V
C507	1-136-169-00	MYLAR	0.22UF	5.00%	50V	C566	1-137-150-11	MYLAR	0.01UF	5.00%	50V
C508 C509	1-126-965-11 1-115-522-11		22UF 1UF	20.00% 5.00%	50V 250V	C567	1-164-161-11	CERAMIC CHIP	0.0022UF	10.00%	50V
C510	1-117-398-11		33UF	20.00%		C568		CERAMIC CHIP		10.00%	50V
C511	1-163-113-00	CERAMIC CHIP	68PF	5.00%	50V	C569 C571	1-126-933-11	ELECT CERAMIC CHIP	100UF 10PF	20.00% 0.50PF	16V 50V
C512		CERAMIC CHIP		5.00%	50V	C572	1-163-009-11	CERAMIC CHIP	0.001UF	10.00%	50V
C513 C514	1-163-017-00 1-106-375-12	CERAMIC CHIP	0.0047UF 0.022UF	10.00%	50V 200V	C573	1-106-375-12	MYLAR	0.022UF		200V
C515		CERAMIC CHIP		10.00%		C575	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
C516	1-126-934-11	FLECT	220UF	20.00%	16V	C576 C577	1-164-222-11 1-126-964-11	CERAMIC CHIP	0.22UF 10UF	20.00%	25V 50V
C517		CERAMIC CHIP		10.00%		C578	1-137-711-61	FILM	0.065UF	5%	400V
C518 C519	1-137-194-81	MYLAR CERAMIC CHIP	0.47UF	5.00% 10.00%	50V 50V	C579	1-135-932-91	FILM	0.015UF	5%	400V
C520	1-107-914-11		1000UF	20.00%		C580	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
C521	1-115-518-11	FII M	0.47UF	5.00%	250V	C701 C702	1-128-560-11 1-128-562-11		22UF 47UF	20.00% 20.00%	
C522	1-137-368-11		0.0047UF		50V	C703	1-104-331-11		0.0022UF	10.00%	
C523 C524	1-137-368-11		0.0047UF		50V 50V	C704	1-104-568-11	CERAMIC	470PF	10.00%	2KV
C524		CERAMIC CHIP		5.00% 10.00%		C706	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V
	1 162 004 04	CEDAMIC CLUD	0.041.15	10.000/	E0\/	C707	1-130-495-00		0.1UF	5.00%	50V
C526 C527		CERAMIC CHIP		10.00% 10.00%		C708 C709	1-126-942-61 1-163-021-91	CERAMIC CHIP	1000UF 0.01UF	20.00% 10.00%	25V 50V
C528	1-117-412-11	FILM	0.24UF	5.00%	250V	C710	1-107-894-11		220UF	20.00%	35V
C529 C530	1-104-665-11 1-163-021-91	CERAMIC CHIP	100UF 0.01UF	20.00% 10.00%		C711	1-163-019-00	CERAMIC CHIP	0.0068UF	10.00%	50V
						C712	1-137-401-11	MYLAR	0.22UF	10.00%	100V
C531 C532	1-117-660-21 1-163-009-11	CERAMIC CHIP	0.12UF 0.001UF	5.00% 10.00%	250V 50V	C713 C715	1-126-942-61 1-164-004-11	CERAMIC CHIP	1000UF 0.1UF	20.00% 10.00%	25V 25V
C533	1-107-889-11	ELECT	220UF	20.00%	25V	C720	1-126-964-11		10UF	20.00%	
C534 C535	1-107-889-11 1-163-021-91	CERAMIC CHIP	220UF 0.01UF	20.00% 10.00%							
		- "									



REF.NO.	PART NO.	DESCRIPTION		REM	IARK	REF.NO.	PART NO.	DESCRIPTION		REMARK
C901	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V	D510		ZENER DIODE		
C902	1-104-665-11	ELECT	100UF	20.00%	25V	D512	8-719-988-61	DIODE FMQ-G5 DIODE 1SS355	ΓE-17	
C903	1-126-964-11	ELECT	10UF	20.00%	50V	D513	8-719-991-33	DIODE 1SS133	Γ-77	
C904	1-104-570-11		0.001UF	10.00%	2KV	D514	8-719-991-33	DIODE 1SS133	Γ-77	
C905		CERAMIC CHIP		5.00%	50V			ZENER DIODE		
C906	1-117-623-11	FILM CERAMIC CHIP	1500PF	3.00%				DIODE 1SS133		
C907	1-163-253-11	CERAINIC CHIP	120PF	5.00%	50V			DIODE 1SS355		
C908		CERAMIC CHIP		10.00%	50V	DEOO	0.740.000.04	DIODE 4000EE	FF 47	
C909 C910	1-126-934-11 1-126-962-11	-	220UF 3.3UF	20.00%	16V 50V			DIODE 1SS355 <sup>-</sup>		
C911		CERAMIC CHIP		10.00%				DIODE 188133		
C912	1-106-383-00		0.047UF	10.00%				DIODE 1SS133		
						D703	8-719-991-33	DIODE 1SS133	Γ-77	
C913	1-119-748-11		33UF	20.00%		D704	4 040 005 04	CHORT	0	
C914 C915	1-106-383-00 1-136-169-00		0.047UF 0.22UF	10.00% 5.00%	200V 50V	D704		DIODE EGP10D	0	
C916	1-117-630-11		3000PF	3.00%		D700		ZENER DIODE		
C917	1-117-665-11		0.33UF	5.00%	250V	D708		DIODE GP08D		
						D709	8-719-948-45	DIODE ERA22-0	)8	
C918	1-106-359-00		0.0047UF	10.00%		D740	0.740.400.05	ZENED DIODE	DD5 450D0	
C919 C920	1-115-350-51 1-137-372-11		0.0047UF 0.022UF	5.00%	2KV 50V			ZENER DIODE   DIODE 1SS133		
C921	1-137-372-11		0.022UF	10.00%		D901		ZENER DIODE		
C922	1-106-220-00		0.1UF	10.00%				DIODE 1SS355		
						D905	8-719-110-36	ZENER DIODE	RD13ES-B2	
C923	1-106-355-12		0.0033UF					DIODE 1/00//00		
C924 C925	1-106-220-00 1-126-967-11		0.1UF 47UF	10.00% 20.00%	100V 50V	D906 D907		DIODE YG911S ZENER DIODE		
C925	1-126-967-11		47UF	20.00%	25V	D907 D908		DIODE RGP02-2		
C927		CERAMIC CHIP	_	5.00%	50V	D909		ZENER DIODE		
						D910	8-719-991-33	DIODE 1SS133	Γ-77	
C928		CERAMIC CHIP		5.00%	50V	D044	0.740.040.00	DIODE DODGO	2051 2004	
C929 C930		CERAMIC CHIP		10.00% 0.50PF	25V 50V	D911		DIODE RGP02-2 DIODE EGP10D		
C931	1-105-227-11		10UF	20.00%	50V			DIODE 1SS133		
C932		CERAMIC CHIP		10.00%	25V			ZENER DIODE		
						D917	8-719-988-61	DIODE 1SS355	ΓE-17	
C933 C935	1-126-960-11	CERAMIC CHIP	1UF	20.00% 5.00%	50V 50V	D019	9 710 001 33	DIODE 1SS133	Г 77	
C936		CERAMIC CHIP		5.00%	50V			DIODE 188133		
C946		CERAMIC CHIP		10.00%	25V			ZENER DIODE		
						D921	8-719-991-33	DIODE 1SS133	Γ-77	
	<connecto< td=""><td>)R&gt;</td><td></td><td></td><td></td><td>D922</td><td>8-719-018-82</td><td>DIODE RGP02-2</td><td>20EL-6394</td><td></td></connecto<>	)R>				D922	8-719-018-82	DIODE RGP02-2	20EL-6394	
	10020.0					D923	8-719-988-61	DIODE 1SS355	ΓE-17	
		PLUG, CONNEC				D925	8-719-018-82	DIODE RGP02-2	20EL-6394	
	^1-564-510-11 *1-508-879-11	PLUG, CONNEC	TOR /P							
		CONNECTOR. F	FFC 25P				<ferrite be<="" td=""><td>EAD&gt;</td><td></td><td></td></ferrite>	EAD>		
CN505	1-784-786-11	CONNECTOR, F	FFC 25P							
ONITOO	4 704 404 44	DINI CONTRICT	OD (DO DO	ADD) 05			1-410-397-21		1.1UH	
		PIN, CONNECTO PLUG, CONNEC	`	ARD) 2P			1-410-397-21		1.1UH 1.1UH	
		PIN, CONNECT		ARD) 10F	<b>-</b>		1-412-911-11 1-412-911-11		1.1UH	
0.1000		, 0020.	0.1 (. 0 20	, t. <del></del> , . o.			1-412-911-11		1.1UH	
	<diode></diode>					FB506	1-410-397-21	FERRITE	1.1UH	
						FB507	1-410-397-21	FERRITE	1.1UH	
		DIODE 1SS3557				FB901	1-410-397-21	FERRITE	1.1UH	
		ZENER DIODE I		2						
		DIODE 1SS1337 DIODE YG911S					<ic></ic>			
		DIODE D5SC4M					102			
								IC BA9759F-E2		
D509	8-719-991-33	DIODE 1SS1331	Γ-77					IC LA6500-FA		
					7.	-8 IC503	8-750-642 66	IC XRA10324AF IC uPC2912HF(	12)	
					•	10304	0-100-040-00	IO UI OZBIZIIF(	12)	



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION		RI	EMARK
IC701	8-759-444-82	IC LA7841L		Q908	8-729-033-25	TRANSISTOR D	TC114GKA		
10004	0.750.505.04	10.04.075050.50				TRANSISTOR D			
IC901	8-759-585-81	IC BA9758FS-E2		Q910	8-729-120-28	TRANSISTOR 2	SC1623-L5	L6	
	<coil></coil>				<resistor></resistor>	•			
L501	1-412-537-31	INDUCTOR 100UH		R501	1-215-884-11	METAL OXIDE	47	5%	2W
L502		INDUCTOR 1MH		R502	1-216-059-00		2.7K		1/10W
L503		INDUCTOR 1MH		R503	1-216-049-91		1K		1/10W
L504 L505		INDUCTOR 4.7MH INDUCTOR 5MH		R504 R505	1-216-025-91 1-216-049-91		100 1K	5% 5%	1/10W 1/10W
L506	1-406-671-11	INDUCTOR 1MH		R506	1-216-049-91	RES-CHIP	1K	5%	1/10W
L901		INDUCTOR 100UH		R507	1-216-097-91		100K		1/10W
L902	1-406-660-41	INDUCTOR 15UH		R508	1-249-409-11	-	220		1/4W
				R509 R510	1-216-049-91 1-216-675-91		1K 10K	5% 0.50%	1/10W 51/10W
	<transisto< td=""><td>OR&gt;</td><td></td><td>K310</td><td></td><td></td><td></td><td></td><td></td></transisto<>	OR>		K310					
0504	0.700.040.40	TRANSPORTER SOLVESSOR SAME	E440	R511	1-216-065-91		4.7K		1/10W
Q501		TRANSISTOR 2SK3262-01MR- TRANSISTOR 2SC1623-L5L6	-F119		1-215-453-00		22K 100	. , -	1/4W
Q502 Q503		TRANSISTOR 2SC1623-L5L6		R513 R514	1-216-025-91 1-216-097-91		100 100K		1/10W 1/10W
Q504		TRANSISTOR 2SC2411K-CQ		R515	1-216-049-91		1K	5%	1/10W
Q505		TRANSISTOR 2SA1036K-Q							
				R516	1-216-049-91		1K		1/10W
Q506		TRANSISTOR 2SK3262-01MR-	-	R517	1-216-685-11	_	27K		1/10W
Q507 Q508		TRANSISTOR 2SK3262-01MR- TRANSISTOR 2SJ569LS-CB11	-	R518 R519	1-216-691-11 1-216-081-00	_	47K 22K		1/10W 1/10W
Q509		TRANSISTOR 250309E3-CBT1	'	R520	1-247-791-91		22		1/10VV 1/4W
Q510		TRANSISTOR 2SK3262-01MR-	-F119			0, 12 0 . 1		0,0	.,
				R521	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
Q511		TRANSISTOR 2SK3262-01MR-		R522	1-249-437-11		47K		1/4W
		TRANSISTOR 2SK3262-01MR-		R523	1-216-033-00		220		1/10W
Q513 Q514		TRANSISTOR 2SK3262-01MR- TRANSISTOR 2SC3209LK	-F119	R524 R525	1-216-025-91 1-216-065-91		100 4.7K		1/10W 1/10W
		TRANSISTOR 2SC5570(LBSO	NY)	11020	1 210 003 31	NEO OF III	7.710	370	1/1000
		`	,	R526	1-216-097-91	RES-CHIP	100K	5%	1/10W
Q516		TRANSISTOR 2SB1565EF		R527		METAL CHIP	8.2K		1/10W
Q517		TRANSISTOR 2SK3262-01MR-	-F119	R528		METAL CHIP	12K		51/10W
Q518 Q519		TRANSISTOR 2SD2394-EF TRANSISTOR DTC114GKA		R529 R530	1-216-057-00 1-216-025-91		2.2K 100	- , -	1/10W 1/10W
		TRANSISTOR 2SC1623-L5L6		11000	1 210 025 51	INEO OF III	100	370	1/1000
				R531	1-216-097-91	RES-CHIP	100K	5%	1/10W
Q521		TRANSISTOR 2SC1623-L5L6		R532		METAL OXIDE			1W
Q522		TRANSISTOR 2SC1623-L5L6		R533	1-211-796-11	METAL CHIP	1		1/2W
Q523 Q524		TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1037AK-T14	16-R	R534 R535	1-216-069-11	_	39K 4.7K		1/10W 1/10W
Q525		TRANSISTOR 2SK3262-01MR	I	11000	1 210 000 01	1120 01111		070	1,1011
				R536		METAL CHIP	22K		1/10W
Q526		TRANSISTOR DTA143TKA-T1		R537	1-249-437-11		47K		1/4W
Q527 Q701		TRANSISTOR 2SK3262-01MR- TRANSISTOR 2SC2362K-G	-F119	R538 R539	1-216-025-91 1-216-097-91		100 100K		1/10W 1/10W
Q701 Q702		TRANSISTOR 25C2362R-G		R540		METAL OXIDE		5%	3W
Q703		TRANSISTOR 2SA1049-GR						0,0	
				R541	1-216-295-91		0		
Q704		TRANSISTOR 2SC3421-Y		R542	1-249-437-11	-	47K		1/4W
Q705		TRANSISTOR 2SA1358-Y	16 D	R543		METAL CHIP	12K		51/10W
Q706 Q707		TRANSISTOR 2SA1037AK-T14 TRANSISTOR 2SC4634LS-CB		R544 R545	1-216-025-91 1-216-097-91		100 100K	5% 5%	1/10W 1/10W
Q901		TRANSISTOR 2SK2655-01R-F		110-10	. 210 007 01	0 0		J / U	.,
				R546	1-219-728-11		0.22	10%	
Q902		TRANSISTOR DTC114EK		R547	1-219-677-11		1.8	5%	10W
Q903		TRANSISTOR 2SC2411K-CQ		R548	1-249-437-11		47K		1/4W
Q904 Q905		TRANSISTOR 2SA1036K-Q TRANSISTOR 2SJ569LS-CB11		R549 R550	1-260-288-11 1-260-288-11		0.47 0.47	5% 5%	1/2W 1/2W
Q905 Q906		TRANSISTOR 2SK2655-01R-F		11000	. 200 200-11	C/ (( DOIN	J.71	J /U	., <u>←</u> ¥ ¥
			ļ	R551	1-216-025-91	RES-CHIP	100	5%	1/10W
Q907	8-729-033-26	TRANSISTOR DTA114GKAT14	46 7-9	0					
			/-:	J					



REF.NO.	PART NO.	DESCRIPTION	1	RI	EMARK	REF.NO.	PART NO.	DESCRIPTION		R	EMARK
R552	1-216-097-91	RES-CHIP	100K	5%	1/10W	R711	1-216-049-91	RES-CHIP	1K	5%	1/10W
R553	1-249-409-11		220		1/4W	R713	1-216-059-00	RES-CHIP	2.7K	5%	1/10W
R554		METAL CHIP	9.1K		1/10W	R714	1-216-057-00		2.2K	5%	1/10W
R555		METAL CHIP	10K		1/10W					-,-	
11000	1 210 070 01		1011	0.0070	, , , , , , , , , , , , , , , , , , , ,	R715	1-249-389-11	CARBON	4.7	5%	1/4W
R556	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	R716	1-216-689-11	-	39K	5%	1/10W
R557		METAL OXIDE	27		1W	R717	1-216-073-00		10K	5%	1/10W
R558	1-249-437-11		47K		1/4W	R718		METAL CHIP	18K		61/10W
R559	1-216-073-00		10K		1/10W	R719		METAL CHIP	3.3K		61/10W
R560		METAL CHIP	10K		1/10W	117.10	1 210 000 11	WETTE OT III	0.011	0.007	31/1011
11000	1 210 070 01	WIE IT LE OI III	1010	0.0070	7171000	R720	1-216-073-00	RES-CHIP	10K	5%	1/10W
R561	1-215-443-00	METAL	8.2K	1%	1/4W	R721	1-216-073-00		10K	5%	1/10W
R562		METAL CHIP	12K		1/10W	R722	1-260-292-11		1	5%	1/2W
R563	1-216-025-91		100		1/10W	R723		METAL CHIP	3.3K		61/10W
R564		METAL CHIP	12K		1/10W	R724	1-216-057-00		2.2K	5%	1/10W
R565	1-216-097-91		100K		1/10W	1072-	1 210 007 00	INEO OF III	2.21	0 70	1/1000
11000	1 210 007 01	KEO OI III	10010	070	17 10 11	R725	1-214-798-21	METAL	1.8	1%	1/2W
R566	1-216-685-11	METAL CHIP	27K	0.50%	1/10W	R726	1-214-798-21		1.8	1%	1/2W
R567	1-214-840-00	_	100		1/2W	R727	1-249-381-11		1	5%	1/4W
R568		METAL CHIP	3.9K		1/20V	R728		METAL OXIDE	220	5%	1W
R569		METAL CHIP	47K		1/10W	R729	1-260-292-11		1	5%	1/2W
R570	1-260-332-51		2.2K		1/2W	17729	1-200-292-11	CARDON	'	370	1/200
K370	1-200-332-31	CARBON	2.2N	5%	1/200	R730	1 216 602 11	METAL CHIP	22K	0.500/	61/10W
R572	1 216 205 11	METAL OXIDE	0.47	5%	3W	R730		METAL CHIP	5.1K		61/10W
R572	1-249-437-11		0.47 47K		1/4W	R731	1-219-510-11		470K	5%	1/2W
		-					1-216-097-91				
R574	1-216-097-91		100K	5%	1/10W	R901			100K	5%	1/10W
R575		METAL CHIP	7.5K		1/10W	R902	1-216-117-00	KES-CHIP	680K	5%	1/10W
R576	1-215-869-11	METAL OXIDE	1K	5%	1W	DOOS	1 216 000 01	DEC CLUD	471/	E0/	1/10\\\
DEZZ	1 200 212 11	CARRON	47	E0/	1/0\\/	R903	1-216-089-91		47K	5%	1/10W
R577	1-260-312-11		47		1/2W	R904	1-216-033-00		220	5%	1/10W
R578	1-216-049-91		1K		1/10W	R905	1-216-097-91		100K	5%	1/10W
R579	1-216-049-91		1K		1/10W	R906	1-216-033-00		220	5%	1/10W
R580	1-214-840-00		100	1%	1/2W	R907	1-216-081-00	RES-CHIP	22K	5%	1/10W
R581	1-260-308-11	CARBON	22	5%	1/2W	B000	4 040 000 00	METAL OVIDE		<b>5</b> 0/	0147
DEGG	4 04 4 0 40 00	NACTAL	400	40/	4 (0) 1 (	R908		METAL OXIDE	6.8	5%	3W
R582	1-214-840-00		100	1%	1/2W	R909	1-216-049-91		1K	5%	1/10W
R583	1-249-437-11		47K	5%	1/4W	R910	1-216-065-91		4.7K	5%	1/10W
R584	1-249-437-11		47K	5%	1/4W	R911	1-216-041-00		470	5%	1/10W
R585	1-216-073-00		10K	5%	1/10W	R912	1-216-049-91	RES-CHIP	1K	5%	1/10W
R586	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	D040	4 040 007 44	DEC CLUD	40016	<b>5</b> 0/	4/40\4/
D=07	4 045 040 44	METAL OVIDE	000	<b>5</b> 0/	0147	R913	1-216-097-11		100K	5%	1/10W
R587		METAL OXIDE	220	5%	3W	R914	1-247-791-91		22	5%	1/4W
R588	1-260-085-11		68	5%	1/2W	R915	1-216-065-91		4.7K	5%	1/10W
R589	1-216-057-00		2.2K	5%	1/10W	R916	1-249-397-11		22	5%	1/4W
R590	1-216-057-00		2.2K		1/10W	R917	1-211-824-71	FUSIBLE	220	5%	1/2W
R591	1-247-807-31	CARBON	100	5%	1/4W	5010					
5-00				=0.	0147	R918	1-219-727-11		68	5%	10W
R592		METAL OXIDE	220		3W	R919	1-219-748-11		4.7K	5%	1/2W
R593	1-216-073-00		10K		1/10W	R920	1-216-089-91		47K	5%	1/10W
R594		METAL CHIP	22K		1/10W	R921	1-215-408-00		300	1%	1/4W
R595		METAL CHIP	2.2K		1/10W	R922	1-249-389-11	CARBON	4.7	5%	1/4W
R597	1-216-073-00	RES-CHIP	10K	5%	1/10W						
						R923		METAL CHIP	220K		61/10W
R598		METAL CHIP	10K		1/10W	R924	1-216-073-00		10K	5%	1/10W
R599		METAL CHIP	1.8K		1/10W	R925	1-220-825-11		330K	5%	1/2W
R701	1-216-049-91		1K		1/10W	R926	1-219-746-11		1K	5%	1/2W
R702	1-249-393-11		10		1/4W	R927	1-219-746-11	CARBON	1K	5%	1/2W
R703	1-215-456-00	METAL	30K	1%	1/4W						
						R928		METAL CHIP	5.1K		61/10W
R704	1-216-651-11	METAL CHIP	1K	0.50%	1/10W	R929	1-216-691-11	METAL CHIP	47K	0.50%	61/10W
R705	1-249-413-11	CARBON	470	5%	1/4W	R930	1-216-653-11	METAL CHIP	1.2K	0.50%	61/10W
R706	1-249-389-11	CARBON	4.7	5%	1/4W	R931		METAL CHIP	1K		61/10W
R707	1-249-389-11	CARBON	4.7	5%	1/4W	R932	1-216-665-11	METAL CHIP	3.9K	0.50%	61/10W
R708	1-215-881-11	METAL OXIDE	15	5%	2W						
						R933	1-216-687-11	METAL CHIP	33K	0.50%	61/10W
R709	1-216-049-91	RES-CHIP	1K	5%	1/10W	R934	1-216-667-11	METAL CHIP	4.7K	0.50%	61/10W
R710	1-216-073-00	RES-CHIP	10K	5%	1/10W	R935	1-216-089-91	RES-CHIP	47K	5%	1/10W
						ı					

The components identified  ${\mathbin{f \vartriangle}}$  marked are

critical for safety.
Replace only with the part number specified.

Les composants identifiés par la marque  ${\mathbb A}$ 

sont critiques pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by **№** in this manual have been carefully factory-selected for eachset in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.





REF.NO.	PART NO.	DESCRIPTION		R	EMARK	REF.NO.	PART NO.	DESCRIPTION		REM	IARK
R937	1-216-065-91 1-216-065-91 1-216-295-91	RES-CHIP	4.7K 4.7K 0	5% 5%	1/10W 1/10W	TH502	1-807-796-11	THERMISTOR			
R940 R941 R942	1-216-049-91 1-216-073-00 1-216-025-91 1-216-073-00	RES-CHIP RES-CHIP RES-CHIP	1K 10K 100 10K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W			G BOARD, CON	1PLETE	******	*****
R945 R1501 R1502 R1503	1-216-065-91 1-216-025-91 1-216-049-91 1-216-033-00 1-216-681-11 1-216-295-91	RES-CHIP RES-CHIP RES-CHIP METAL CHIP	4.7K 100 1K 220 18K 0	5% 5%	1/10W 1/10W 1/10W 1/10W 61/10W			SCREW (M3X10 (IC652, IC654, G D610, D652, D6 SCREW +PSW	0), P, SW (+ 2620, Q621, 80)	Q630, Q	651,
R1505 R1506 R1507	1-216-667-11 1-216-025-91 1-216-097-91	METAL CHIP RES-CHIP RES-CHIP	4.7K 100 100K	5% 5%	61/10W 1/10W 1/10W		<capacitor< td=""><td>₹&gt;</td><td>·</td><td></td><td></td></capacitor<>	₹>	·		
R1515 R1518	1-216-073-00 1-215-909-11 1-216-025-91 1-249-437-11	METAL OXIDE RES-CHIP	10K 47 100 47K	5% 5% 5% 5%	1/10W 3W 1/10W 1/4W	C602 <u>A</u> C603 <u>A</u> C604 <u>A</u>	\( 1-113-513-11 \( 1-113-513-11 \( 1-113-900-51 \( 1-113-926-91 \( 1-113-926-91	FILM CERAMIC CERAMIC	1UF 1UF 470PF 470PF 0.0047UF	20.00% 20.00% 10.00% 10.00%	275V 250V
	1-216-097-91 1-216-025-91 <variable i<="" td=""><td>RES-CHIP</td><td>100K 100</td><td>5% 5%</td><td>1/10W 1/10W</td><td>C607 <u></u></td><td></td><td>-</td><td></td><td>10.00% 10.00% 10.00%</td><td></td></variable>	RES-CHIP	100K 100	5% 5%	1/10W 1/10W	C607 <u></u>		-		10.00% 10.00% 10.00%	
■ RV901		21 RES, ADJ, CE	ERMET 100	K (HV	ADJ)	C610 C611	1-117-849-11 1-137-479-11	ELECT MYLAR	330UF 1UF	20.00%	450V 400V
RY501	<relay> 1-755-198-11</relay>	RELAY				C613 C614	1-136-169-00 1-126-967-11 1-163-251-11 1-137-150-11	ELECT CERAMIC CHIP	0.22UF 47UF 100PF 0.01UF	5.00% 20.00% 5.00% 5.00%	50V 50V 50V 50V
	<spark gai<="" td=""><td><sup>-</sup>&gt;</td><td></td><td></td><td></td><td>C631</td><td>1-107-910-11</td><td>CERAMIC CHIP ELECT CERAMIC CHIP</td><td>100UF</td><td>10.00% 20.00% 10.00%</td><td>50V 50V 50V</td></spark>	<sup>-</sup> >				C631	1-107-910-11	CERAMIC CHIP ELECT CERAMIC CHIP	100UF	10.00% 20.00% 10.00%	50V 50V 50V
SG902	1-519-422-11	GAP, SPARK GAP, SPARK GAP, SPARK				C634 C639	1-163-009-11 1-135-833-21	CERAMIC CHIP FILM	0.001UF 18000PF	10.00% 3%	50V 800V
	<transfor< td=""><td>RMER&gt;</td><td></td><td></td><td></td><td>C641</td><td>1-126-964-11 1-162-115-00 1-136-165-00 1-162-115-00</td><td>CERAMIC MYLAR</td><td>10UF 330PF 0.1UF 330PF</td><td>20.00% 10.00% 5.00% 10.00%</td><td>50V 1KV 50V 1KV</td></transfor<>	RMER>				C641	1-126-964-11 1-162-115-00 1-136-165-00 1-162-115-00	CERAMIC MYLAR	10UF 330PF 0.1UF 330PF	20.00% 10.00% 5.00% 10.00%	50V 1KV 50V 1KV
T501 T502 T503	1-429-301-11 1-426-998-11	TRANSFORME TRANSFORME TRANSFORME	R, FERRITE R, FERRITE	(HCT	) )	C644	1-136-479-11		0.001UF	10.00%	50V 50V
T505 T701 T901	1-435-719-11	COIL,HORIZON TRANSFORMEI INDUCTOR 500	R, FERRITE			C646 C647 C648 C649	1-126-961-11 1-126-964-11 1-126-967-11 1-163-009-11	ELECT	2.2UF 10UF 47UF 0.001UF	20.00% 20.00% 20.00% 10.00%	50V 50V 50V 50V
	. 8-598-861-00	TRANSFORME			K NX-4504)	C650 C651 C652	1-107-656-11 1-107-651-11 1-128-563-11	ELECT ELECT ELECT	100UF 4.7UF 100UF	20.00% 20.00% 20.00%	250V 250V 100V
TH501	<thermisto 1-807-796-11</thermisto 	OR> THERMISTOR				C653 C654	1-128-581-11 1-111-070-51		4.7UF 2200UF	20.00% 20.00%	100V 25V
		5.5.				C655 C656 C657 C658 C659	1-104-664-11 1-111-070-51 1-104-664-11 1-126-927-11 1-128-339-11	ELECT ELECT ELECT	47UF 2200UF 47UF 2200UF 2200UF	20.00% 20.00% 20.00% 20.00% 20.00%	25V 25V 25V 10V 10V

# **GDM-FW9011**



Les composants identifiés par la marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified  ${\mathbin{f \vartriangle}}$  marked are critical for safety.
Replace only with the part number specified.

REF.NO.	PART NO.	DESCRIPTION		REM	IARK	REF.NO.	PART NO.	DESCRIPTION	l	REMARK
C662	1-102-244-00 1-137-150-11 1-107-909-11 1-107-909-11 1-115-747-51	MYLAR ELECT ELECT	220PF 0.01UF 47UF 47UF 0.0068F	10.00% 5.00% 20.00% 20.00% 20.00%	500V 50V 10V 16V 10V	FB630 FB632	<ferrite 1-410-396-4="" 1-410-397-3<="" be="" td="" ⚠=""><td>11 FERRITE</td><td>0.45UH 1.1UH</td><td></td></ferrite>	11 FERRITE	0.45UH 1.1UH	
C683 C684 C685 C686	1-104-664-11 1-137-368-11 1-104-664-11 1-107-889-11 1-128-526-11 1-104-664-11 1-115-339-11	MYLAR ELECT ELECT ELECT	47UF 0.0047UF 47UF 220UF 100UF 47UF	20.00% 5.00% 20.00% 20.00% 20.00% 20.00% 10.00%	10V 50V 10V 10V 10V	IC620 IC630 IC650	<ic> 8-749-015-27 8-759-670-30 8-759-535-32 8-749-012-49 8-759-592-79</ic>	IC MCZ3001D IC FA13842P		
CN601 CN602 CN603 CN605	<connectc *1-580-689-11="" *1-691-960-11="" 1-900-251-20<="" td=""><td></td><td>OR (PC BC OR (PC BC OR (PC BC \SSY</td><td>ARD) 4P ARD) 3P</td><td>301</td><td>IC652 IC653 IC654</td><td>8-759-496-15 8-759-450-47 8-759-643-66</td><td>IC BA05ST-V5</td><td></td><td></td></connectc>		OR (PC BC OR (PC BC OR (PC BC \SSY	ARD) 4P ARD) 3P	301	IC652 IC653 IC654	8-759-496-15 8-759-450-47 8-759-643-66	IC BA05ST-V5		
CN651 CN652 CN653 CN654	*1-564-507-11 *1-564-512-11 *1-564-509-11 *1-764-333-11	PLUG, CONNEC PLUG, CONNEC PLUG, CONNEC PLUG, CONNEC PLUG, CONNEC	CTOR 4P CTOR 9P CTOR 6P CTOR 10P				1-419-726-11 1-414-742-21 1-414-742-21 1-406-661-21 1-406-661-21	INDUCTOR 230 INDUCTOR 100 INDUCTOR 22L INDUCTOR 22L INDUCTOR 22L	OUH JH JH JH	
D610∆	8-719-510-53	DIODE MA111-(	,			L680	<photo col<="" td=""><td></td><td></td><td></td></photo>			
D620 D630 D631	8-719-110-57 8-719-110-57 8-719-063-73	DIODE RM11C ZENER DIODE ZENER DIODE DIODE D1NL20	RD22ES-B2 U-TR			PH620	8-749-010-64 8-749-010-64	PHOTO COUPL PHOTO COUPL PHOTO COUPL	ER PC123F2	
D633 D635	8-719-069-63 8-719-110-53	DIODE P6KE20 DIODE ERB38-0 ZENER DIODE DIODE 1SS119-	06V1 RD20ES-B2	2				31 LINK, IC (2A/9 31 LINK, IC (4A/9		
D650 D651 D652	8-719-064-49 8-719-063-73 8-719-052-91	DIODE ERB38-0 DIODE D4SBL4 DIODE D1NL20 DIODE D4SBS4 DIODE D2S4MF	0 U-TR I-F					R> TRANSISTOR 2 TRANSISTOR 2		6-R
D654 D655 D664	8-719-022-97 8-719-063-73 8-719-110-57	DIODE D2S4MF DIODE D1NL20 ZENER DIODE	: U-TR RD22ES-B2	2		Q612 Q613 Q620	8-729-120-28 8-729-027-23 8-729-053-36	TRANSISTOR 2 TRANSISTOR D TRANSISTOR 2	2SC1623-L5L6 DTA114EKA-T14 2SK2640-010MR	16
D681 D682 D690	8-719-109-89 8-719-929-15 8-719-911-19	ZENER DIODE ZENER DIODE DIODE 1SS119	RD5.6ES-B HZS9.1NB2 -25			Q630 Q631 Q632	8-729-045-03 8-729-041-66 8-729-041-66	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2	2SK2647-01MR- 2SC4015TV2 2SC4015TV2	
	<fuse></fuse>	FUSE (H.B.C.) (				Q653 Q667 Q671	8-729-120-28 8-729-026-49 8-729-026-49	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2	2SC1623-L5L6 2SA1037AK-T14 2SA1037AK-T14	6-R
FH1 FH2	1-533-223-11	HOLDÈR, FUSÈ HOLDER, FUSE	; F601				<resistor></resistor>			

The components identified  $\underline{\mathbb{A}}$  marked are critical for safety. Replace only with the part number specified.

Les composants identifiés par la marque A sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.



**GDM-FW9011** 

REF.NO.	PART NO.	DESCRIPTION	I	RI	EMARK	REF.NO.	PART NO.	DESCRIPTION	l	RI	EMARK
						R673	1-216-073-00	RES-CHIP	10K	5%	1/10W
R601 △	1-220-825-91	CARBON	330K	5%	1/2W						
		METAL OXIDE	27K		2W	R674	1-216-097-91	RES-CHIP	100K	5%	1/10W
	1-247-895-91		470K		1/4W			METAL CHIP	3.3K		61/10W
			470K 470K					_	5.1K		
	1-216-113-00				1/10W			METAL CHIP			61/10W
R605	1-216-113-00	RES-CHIP	470K	5%	1/10W			METAL CHIP METAL OXIDE	2.7K 1.2		61/10W 3W
R606	1-216-097-91	RES-CHIP	100K	5%	1/10W						
	1-216-097-91		100K		1/10W	R680	1-215-475-00	METAI	180K	1%	1/4W
	1-216-073-00		10K		1/10W	R681	1-216-073-00		10K	5%	1/10W
	1-216-069-00		6.8K		1/10W		1-216-049-91		1K	5%	1/10W
				10%							
R610	1-217-152-00	WETAL	0.33	10%	ZVV		1-216-041-00 1-216-033-00		470 220	5% 5%	1/10W 1/10W
R611	1-217-152-00	METAL	0.33	10%	2W						
R612	1-249-425-11	CARBON	4.7K	5%	1/4W	R687	1-216-081-00	RES-CHIP	22K	5%	1/10W
	1-216-089-91		47K	5%	1/10W	R688	1-215-473-00	METAI	150K	1%	1/4W
	1-247-807-31		100		1/4W	R691	1-216-049-91		1K	5%	1/10W
	1-249-427-11		6.8K		1/4W		1-216-057-00		2.2K	5%	1/10W
KOIS	1-245-421-11	CARBON	U.OK	J /0	1/4 0 0		1-260-085-11		68	5%	1/10VV 1/2W
R616	1-216-671-11	METAL CHIP	6.8K	0.50%	1/10W						
R617	1-249-417-11	CARBON	1K	5%	1/4W	R694	1-216-073-00	RES-CHIP	10K	5%	1/10W
		METAL OXIDE	1		2W		1-216-065-91		4.7K	5%	1/10W
	1-216-049-91		1K		1/10W		1-249-407-11		150	5%	1/4W
R620	1-202-933-61	FUSIBLE	0.1	10%	1/200		1-216-073-00		10K	5%	1/10W
						R699	1-202-933-61	FUSIBLE	0.1	10%	1/2W
	1-219-512-11	CARBON	2.2M		1/2W						
R622	1-216-683-11	METAL CHIP	22K	0.50%	51/10W						
R623	1-216-671-11	METAL CHIP	6.8K	0.50%	1/10W		<relay></relay>				
	1-216-627-11	METAL CHIP	100		1/10W						
	1-249-393-11		10		1/4W	RY602	<b>↑ 1-755-318-</b>	11 RELAY, POW	/FR		
							△ 1-755-067-	·	LIX		
R626	1-249-429-11	CARBON	10K	5%	1/4W						
R627	1-249-393-11	CARBON	10	5%	1/4W						
R628	1-249-429-11	CARBON	10K	5%	1/4W		<spark gar<="" td=""><td><sup>0</sup>&gt;</td><td></td><td></td><td></td></spark>	<sup>0</sup> >			
R629	1-249-410-11	CARBON	270	5%	1/4W						
	1-249-387-11		3.3		1/4W	SG601	₾ 1-533-982-	21 GAP, SPARK			
R631	1-247-807-31	CARBON	100	5%	1/4W						
	1-215-381-00		22		1/4W		<transfor< td=""><td>MFR&gt;</td><td></td><td></td><td></td></transfor<>	MFR>			
	1-260-135-11		1M		1/2W		1110 11101 011	WILI ()			
	1-260-135-11					TC04 A	1 105 710 11	TDANCEODME	D LINIE EIL:	TED	
		-	1M		1/2W			TRANSFORME	,		DIT\
R635	1-216-465-11	METAL OXIDE	2/K	5%	2W			TRANSFORME TRANSFORME			
R636	1-249-433-11	CARBON	22K	5%	1/4W					`	•
	1-215-485-00		470K	1%	1/4\/\						
	1-215-481-00		330K	1%	1/4W		<thermisto< td=""><td>NR~</td><td></td><td></td><td></td></thermisto<>	NR~			
	1-215-481-00		330K	1%	1/4W		< THE KIND TO				
						TU604	A 1 000 000	44 THEDMICTO			
R642	1-216-695-11	METAL CHIP	68K	0.50%	51/10W			11 THERMISTO 31 THERMISTO		Ε	
R643	1-216-381-11	METAL OXIDE	0.22	5%	3W						
	1-216-073-00		10K		1/10W						
	1-216-073-00		10K		1/10W		<varistor></varistor>				
	1-249-437-11		47K		1/4W		V/11(10101)				
						VDB60	1 1 1 001 260	E4 VADICTOD T	NID44\/474L	/ee0	
R650	1-216-057-00	RES-CHIP	2.2K	5%	1/10W	VDR60	121 1-001-200-	51 VARISTOR T	NK 14 V 47 1 r	0000	
R651	1-219-512-11	CARBON	2.2K	5%	1/2W						
R652	1-216-073-00	RES-CHIP	10K	5%	1/10W						
R664	1-216-073-00	RES-CHIP	10K	5%	1/10W	********	******	******	******	*****	*****
	1-216-057-00		2.2K		1/10W						
	1-216-073-00		10K		1/10W						
11000	. 210-075-00		1011	J /0	17 10 4 4	*	8-933-432-00	A BOARD, COM	IPLETE		
R667	1-216-089-91	RES-CHIP	47K	5%	1/10W			*******	*****		
	1-215-457-00		33K		1/4W						
		METAL CHIP	12K		51/10W						
		METAL CHIP	12K		51/10W		7-682-050-04	SCREW +PSW	3¥12 (IC40	3/	
							,-002-330-01	JONEW TESW	JA 12 (1040)	)	
R672	1-210-003-11	METAL CHIP	3.3K	0.50%	51/10W						



REF.NO.	PART NO.	DESCRIPTION		REM	ARK	REF.NO.	PART NO.	DESCRIPTION		REM	IARK
	<capacitor< td=""><td>₹&gt;</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></capacitor<>	₹>									
						C408	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
C101		CERAMIC CHIP		10.00%	50V	C410		CERAMIC CHIP		10.00%	50V
C102	1-104-664-11		47UF	20.00%	25V	C411	1-104-664-11		47UF	20.00%	25V
C103		CERAMIC CHIP		10.00%	50V			CERAMIC CHIP		10.00%	25V
C104 C107	1-104-664-11 1-164-004-11	CERAMIC CHIP	47UF 0.1UF	20.00%	25V 25V	C413	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
0.0.		02.0.000		1010070	_0.	C415	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V
C108	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V		1-126-961-11		2.2UF	20.00%	50V
C109	1-163-239-11	CERAMIC CHIP	33PF	5.00%	50V	C417	1-104-574-11	CERAMIC	0.0047UF	10.00%	2KV
C110	1-163-275-11	CERAMIC CHIP	0.001UF	5.00%	50V	C419	1-162-318-11	CERAMIC	0.001UF	10.00%	500V
C111	1-163-227-11	CERAMIC CHIP	10PF	0.50PF	50V	C420	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V
C112	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V	0.404		0554440 0145	0.4115	40.000/	05) (
C112	1 164 400 11	CEDAMIC CLUD	0.00115	10.000/	16\/	C421		CERAMIC CHIP		10.00%	25V
C113 C114		CERAMIC CHIP		10.00% 10.00%	16V 25V	C422 C423	1-164-489-11	CERAMIC CHIP	0.220F 47UF	10.00% 20.00%	16V 25V
C114 C115	1-136-189-00		0.1UF	10.00%		C423	1-162-318-11		0.001UF	10.00%	
C117		CERAMIC CHIP		10.00%	25V	C425		CERAMIC CHIP		5.00%	50V
C120			0.1UF	10.00%		0 120	1 100 201 11	OLI WIND OF III	10011	0.0070	001
						C426	1-163-251-11	<b>CERAMIC CHIP</b>	100PF	5.00%	50V
C201	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V	C427		CERAMIC CHIP		5.00%	50V
C202	1-104-664-11		47UF	20.00%	25V	C430	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
C203		CERAMIC CHIP		10.00%	50V	C431		CERAMIC CHIP		5.00%	50V
C204	1-104-664-11		47UF	20.00%	25V	C432	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V
C205	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V	0.400	4 400 040 44	OFDANIO	0.004115	40.000/	500)/
0000	4 400 000 44	CEDAMIC CLUD	41.15	40.000/	40)/	C433	1-162-318-11		0.001UF	10.00%	
C206 C207		CERAMIC CHIP		10.00% 10.00%	10V 25V	C434 C435	1-162-318-11		0.001UF	10.00% 10.00%	
C207		CERAMIC CHIP		10.00%	25V 25V	C436		CERAMIC CHIP		10.00%	50V 16V
C209		CERAMIC CHIP		5.00%	50V	C437	1-126-934-11		220UF	20.00%	16V
C210		CERAMIC CHIP		5.00%	50V	0 107	1 120 001 11		22001	20.0070	101
						C438	1-115-339-11	CERAMIC CHIP	0.1UF	10.00%	50V
C211	1-163-227-11	CERAMIC CHIP	10PF	0.50PF	50V	C440	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
C212		CERAMIC CHIP		10.00%	16V	C441		CERAMIC CHIP		10.00%	50V
C213		CERAMIC CHIP		10.00%	16V	C442		CERAMIC CHIP		10.00%	50V
C214		CERAMIC CHIP		10.00%	25V	C443	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
C215	1-136-189-00	MYLAR	0.1UF	10.00%	250V	C444	1 160 010 11	CEDAMIC	0.004115	10.00%	E00\/
C216	1_163_021_01	CERAMIC CHIP	0.0111E	10.00%	50V	C444 C446	1-162-318-11 1-104-664-11		0.001UF 47UF	20.00%	25V
C210		CERAMIC CHIP		10.00%	25V	C449		CERAMIC CHIP	-	10.00%	10V
C220	1-136-189-00		0.1UF	10.00%		C450		CERAMIC CHIP		10.00%	16V
C301		CERAMIC CHIP		10.00%	50V	C452		CERAMIC CHIP	-	10.00%	25V
C302	1-104-664-11	ELECT	47UF	20.00%	25V						
								CERAMIC CHIP		10.00%	25V
		CERAMIC CHIP		10.00%	50V			CERAMIC CHIP		10.00%	
C304	1-104-664-11		47UF	20.00%	25V			CERAMIC CHIP		10.00%	50V
C307		CERAMIC CHIP		10.00%	25V	C459	1-128-560-11		22UF	20.00%	
C308 C309		CERAMIC CHIP		10.00% 5.00%	25V 50V	C462	1-115-339-11	CERAMIC CHIP	0.10F	10.00%	50V
0000	1 100 200 11	OLIV WIIO OI III	001 1	0.0070	001	C463	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V
C310	1-163-275-11	CERAMIC CHIP	0.001UF	5.00%	50V	C464		CERAMIC CHIP		10.00%	50V
C311	1-163-227-11	CERAMIC CHIP	10PF	0.50PF	50V	C467	1-107-957-11	ELECT	1UF	20.00%	250V
C312	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V						
C313	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V						
C314	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V		<connecto< td=""><td>)R&gt;</td><td></td><td></td><td></td></connecto<>	)R>			
C315	1-136-189-00	MYI AR	0.1UF	10.00%	250\/	CN401	1-793-183-11	CONNECTOR. [	SUB 15P		
C317		CERAMIC CHIP		10.00%	25V			PLUG, CONNEC			
C320	1-136-189-00		0.1UF	10.00%				CONNECTOR, F		IP	
C401	1-126-964-11		10UF	20.00%	50V			PLUG, CONNEC			
C402	1-104-664-11	ELECT	47UF	20.00%	25V	CN406	*1-766-179-11	PIN, CONNECTO	OR (PC BO	ARD) 2P	
C403	1_163_250_04	CERAMIC CHIP	220PE	5.00%	50V						
C403		CERAMIC CHIP		5.00%	50V		<diode></diode>				
C405		CERAMIC CHIP		10.00%	25V		.5.052				
C406		CERAMIC CHIP		10.00%	50V	D101	8-719-062-51	DIODE 1PS226-	115		
C407	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V	D102	8-719-062-51	DIODE 1PS226-	115		
						D103	8-719-066-10	DIODE 1PS181-	115		

The components identified  ${\mathbin{f \vartriangle}}$  marked are critical for safety.
Replace only with the part number specified.

Les composants identifiés par la marque A sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	I	R	EMARK
D105	0.710.051.05	DIODE LICCOSTD							
		DIODE HSS83TD		0.404	0.700.400.00	TD ANIQUOTOD (	2004000 1 51	_	
D106	8-719-052-12	DIODE 1SS376TE-17				TRANSISTOR 2			
		DIODE (000-075 (-				TRANSISTOR 2			
		DIODE 1SS376TE-17				TRANSISTOR 2			
		DIODE 1PS226-115				TRANSISTOR 2			
		DIODE 1PS226-115		Q402	8-729-050-41	TRANSISTOR 2	2SJ360-TE12	L	
		DIODE 1PS181-115							
D205	8-719-051-85	DIODE HSS83TD				TRANSISTOR 2			
						TRANSISTOR I		T106	
		DIODE 1SS376TE-17		Q410	8-729-032-61	TRANSISTOR 2	2SC5022-02		
		DIODE 1SS376TE-17							
		DIODE 1PS226-115							
		DIODE 1PS226-115			<resistor></resistor>	•			
D303	8-719-066-10	DIODE 1PS181-115							
						METAL		1%	1/4W
D305	8-719-051-85	DIODE HSS83TD		R103	1-215-394-00	METAL	75	1%	1/4W
D306	8-719-052-12	DIODE 1SS376TE-17		R104	1-216-049-91	RES-CHIP	1K	5%	1/10W
D307	8-719-052-12	DIODE 1SS376TE-17		R105	1-216-017-91	RES-CHIP	47	5%	1/10W
D402	8-719-801-78	DIODE 1SS184		R106	1-216-017-91	RES-CHIP	47	5%	1/10W
D403	8-719-982-36	ZENER DIODE MTZJ-39B							
				R107	1-216-045-00	RES-CHIP	680	5%	1/10W
D405	8-719-911-19	DIODE 1SS119-25		R109	1-216-075-00	RES-CHIP	12K	5%	1/10W
D406	8-719-062-51	DIODE 1PS226-115		R110	1-216-097-91	RES-CHIP	100K	5%	1/10W
D407	8-719-062-51	DIODE 1PS226-115		R111	1-216-041-00	RES-CHIP	470	5%	1/10W
				R112	1-216-015-00	RES-CHIP	39	5%	1/10W
	<ferrite bi<="" td=""><td>EAD&gt;</td><td></td><td>R113</td><td>1-216-017-91</td><td>RES-CHIP</td><td>47</td><td>5%</td><td>1/10W</td></ferrite>	EAD>		R113	1-216-017-91	RES-CHIP	47	5%	1/10W
				R114	1-216-009-91	RES-CHIP	22	5%	1/10W
FB402	1-412-911-11	FERRITE 1.1UH		R115	1-219-742-11	CARBON	47	5%	1/2W
FB403	1-412-911-11	FERRITE 1.1UH		R116	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
FB404	1-412-911-11	FERRITE 1.1UH		R117	1-216-121-91	RES-CHIP	1M	5%	1/10W
FB405	1-412-911-11	FERRITE 1.1UH							
FB406	1-412-911-11	FERRITE 1.1UH		R118	1-216-121-91	RES-CHIP	1M	5%	1/10W
				R119	1-216-077-91	RES-CHIP	15K	5%	1/10W
FB411	1-412-911-11	FERRITE 1.1UH		R120	1-216-113-00	RES-CHIP	470K	5%	1/10W
				R121	1-216-113-00	RES-CHIP	470K	5%	1/10W
				R122	1-216-081-00	RES-CHIP	22K	5%	1/10W
	<ic></ic>								
				R128	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
IC401	8-759-584-87	IC M52757FP-TP		R130	1-216-113-00	RES-CHIP	470K	5%	1/10W
IC402	8-759-584-86	IC M52749FP-TP		R137	1-249-412-11	CARBON	390	5%	1/4W
IC403	8-749-015-91	IC FA4301		R138	1-216-027-00	RES-CHIP	120	5%	1/10W
IC404	8-759-585-72	IC CXD9514M		R161	1-216-041-00	RES-CHIP	470	5%	1/10W
IC405	8-759-701-01	IC NJM2904M							
				R201	1-215-394-00	METAL	75	1%	1/4W
IC406	8-749-015-92	IC H8D2972		R202	1-216-097-91			5%	1/10W
IC407	8-759-925-74	IC SN74HC04ANS		R203	1-215-394-00	METAL	75	1%	1/4W
				R204	1-216-049-91			5%	1/10W
				R205	1-216-017-91			5%	1/10W
	<coil></coil>								
				R206	1-216-017-91	RES-CHIP	47	5%	1/10W
L101	1-410-805-11	INDUCTOR 68NH		R207	1-216-045-00			5%	1/10W
L201		INDUCTOR 68NH		R209	1-216-075-00			5%	1/10W
L301		INDUCTOR 68NH		R210	1-216-097-91			5%	1/10W
L402		INDUCTOR 22UH		R211	1-216-025-91			5%	1/10W
L403		INDUCTOR 100UH				:			
2.50				R212	1-216-019-00	RES-CHIP	56	5%	1/10W
L404	1-414-940-21	INDUCTOR 100UH		R213	1-216-017-91			5%	1/10W
L405		INDUCTOR 22UH		R214	1-216-009-91			5%	1/10W
L-100	1 -12 020-11			R215	1-219-742-11			5%	1/10VV 1/2W
				R216	1-216-065-91			5% 5%	1/2VV 1/10W
	<ic link=""></ic>			11210	1-210-000-91	NEO OI III	7.713	J /0	1/1000
	/IC LINK>			R217	1-216-121-91	RES-CHIP	1M	5%	1/10W
DC/104	<b>↑ 1-533 500</b>	31 LINK, IC (1A/90V AC, 60V	DC)	R217	1-216-121-91			5% 5%	1/10W
F 3401	<u></u>	51 LINK, IC (1A/90 / AC, 60 /	DO)	R216	1-216-121-91				1/10W
				R219 R220				5% 5%	1/10W
	-TD A NICIOTA	)P.			1-216-113-00			5% 5%	
	<transisto< td=""><td>JN&gt;</td><td></td><td>R221</td><td>1-216-113-00</td><td>KES-CHIP</td><td>470K</td><td>5%</td><td>1/10W</td></transisto<>	JN>		R221	1-216-113-00	KES-CHIP	470K	5%	1/10W

# **GDM-FW9011**



Les composants identifiés par la marque △

sont critiques pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified  ${\mathbin{f \vartriangle}}$  marked are critical for safety.

Replace only with the part number specified.

			-								
REF.NO.	PART NO.	DESCRIPTION	ı	R	EMARK	REF.NO.	PART NO.	DESCRIPTION		R	EMARK
						D 404	4 040 440 00	DEO OLUD	4701/	<b>5</b> 0/	4/40\\\
						R431	1-216-113-00		470K	5%	1/10W
R222	1-216-081-00	RES-CHIP	22K	5%	1/10W	R436	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R228	1-216-065-91	RES-CHIP	4.7K	5%	1/10W	R438	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R230	1-216-113-00	RES-CHIP	470K	5%	1/10W	R439	1-216-041-00	RES-CHIP	470	5%	1/10W
R237	1-249-412-11		390	5%	1/4W	R441	1-216-121-91		1M	5%	1/10W
R238	1-216-027-00		120	5%	1/10W	13771	1 210 121 01	INEO OF III	1101	0 / 0	171000
11230	1-210-021-00	KL3-CHIF	120	3 /0	1/1000	D440	1 246 040 04	DEC CLUD	11/	E0/	4/40\\
5001		556 01115				R442	1-216-049-91		1K	5%	1/10W
R261	1-216-041-00		470	5%	1/10W	R443	1-216-025-91		100	5%	1/10W
R301	1-215-394-00	METAL	75	1%	1/4W	R444	1-216-025-91	RES-CHIP	100	5%	1/10W
R303	1-215-394-00	METAL	75	1%	1/4W	R445	1-216-025-91	RES-CHIP	100	5%	1/10W
R304	1-216-049-91	RES-CHIP	1K	5%	1/10W	R446	1-216-025-91	RES-CHIP	100	5%	1/10W
R305	1-216-017-91		47	5%	1/10W						
11000	1 210 011 01	1120 01111		0 70	171011	R447	1-216-017-91	RES-CHIP	47	5%	1/10W
Dane	1 016 017 01	DEC CLUD	47	E0/	4/40\\						
R306	1-216-017-91		47	5%	1/10W	R448	1-216-017-91		47	5%	1/10W
R307	1-216-045-00		680	5%	1/10W	R449	1-216-081-00		22K	5%	1/10W
R309	1-216-075-00	RES-CHIP	12K	5%	1/10W	R450	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R310	1-216-097-91	RES-CHIP	100K	5%	1/10W	R451	1-216-129-00	RES-CHIP	2.2M	5%	1/10W
R311	1-216-041-00	RES-CHIP	470	5%	1/10W						
						R453	1-216-073-00	RES-CHIP	10K	5%	1/10W
R312	1-216-017-91	DEC CHID	47	5%	1/10W	R454	1-216-129-00		2.2M	5%	1/10W
						I					
R313	1-216-017-91		47	5%	1/10W	R455	1-216-097-91		100K	5%	1/10W
R314	1-216-009-91	RES-CHIP	22	5%	1/10W	R456	1-216-025-91		100	5%	1/10W
R315	1-219-742-11	CARBON	47	5%	1/2W	R457	1-211-895-11	METAL	10M	10%	1/4W
R316	1-216-065-91	RES-CHIP	4.7K	5%	1/10W						
						R458	1-219-398-51	METAI	2.2M	5%	1W
R317	1-216-121-91	RES-CHIP	1M	5%	1/10W	R459	1-211-895-11		10M		1/4W
R318	1-216-121-91		1M	5%	1/10W	R460	1-216-073-00		10K	5%	1/10W
R319	1-216-077-91		15K	5%	1/10W	R463	1-216-097-91		100K	5%	1/10W
R320	1-216-113-00	RES-CHIP	470K	5%	1/10W	R464	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R321	1-216-113-00	RES-CHIP	470K	5%	1/10W						
						R488	1-216-089-91	RES-CHIP	47K	5%	1/10W
R322	1-216-081-00	RES-CHIP	22K	5%	1/10W	R490	1-216-065-91		4.7K	5%	1/10W
R328	1-216-065-91		4.7K	5%	1/10W	R491	1-216-065-91		4.7K	5%	1/10W
						11491	1-210-003-91	KL3-CHIF	4.71	J /0	1/1000
R330	1-216-113-00		470K	5%	1/10W						
R337	1-249-412-11		390	5%	1/4W						
R338	1-216-027-00	RES-CHIP	120	5%	1/10W		<spark gaf<="" td=""><td>P&gt;</td><td></td><td></td><td></td></spark>	P>			
R361	1-216-041-00	RES-CHIP	470	5%	1/10W	SG101	1-576-354-21	GAP, SPARK			
R402	1-216-049-91	RES-CHIP	1K	5%	1/10W	SG201	1-576-354-21	GAP, SPARK			
R403	1-216-081-00	RES-CHIP	22K	5%	1/10W	SG301	1-576-354-21	GAP, SPARK			
R404	1-216-057-00		2.2K	5%	1/10W	I		GAP, SPARK			
R405	1-216-045-00		680	5%	1/10W	l		GAP, SPARK			
K405	1-210-043-00	KES-CHIP	000	3%	1/1000	36402	1-319-422-11	GAF, SFARK			
D 400	4 040 007 04	DEO OLUD	40016	<b>50</b> /	4 /4 0 \ \ \ \						
R406	1-216-097-91		100K	5%	1/10W		0001/55				
R407	1-218-768-11	METAL CHIP	470K	$0.50^{\circ}$	%1/10W		<socket></socket>				
R409	1-216-129-00	RES-CHIP	2.2M	5%	1/10W						
R411	1-216-065-91	RES-CHIP	4.7K	5%	1/10W	SK401	₾ 1-451-524-	11 SOCKET, PIC	TURE TUB	3E	
R412	1-216-105-91	RES-CHIP	220K	5%	1/10W			•			
R413	1-216-097-91	RES-CHIP	100K	5%	1/10W		<crystal></crystal>				
R414	1-216-089-91		47K	5%			CONTOTAL				
					1/10W	V404	4 704 470 04	VIDDATOD OF	D A A 410 (OA 4		
R415	1-216-097-91		100K	5%	1/10W	X401	1-781-472-21	VIBRATOR, CE	RAMIC (8M	HZ)	
R417	1-216-121-91		1M	5%	1/10W						
R418	1-260-127-11	CARBON	220K	5%	1/2W						
R419	1-216-033-00	RES-CHIP	220	5%	1/10W	******	******	******	******	******	******
R420	1-216-025-91	RES-CHIP	100	5%	1/10W						
R421	1-216-025-91		100	5%	1/10W						
R422	1-216-025-91		100	5%	1/10W	,	* 8-033-430 <sub>-</sub> 00	BLOCK ASSY, (	CONTROL	H R∩/	/BD/
							0-300-403-00	***********			
R424	1-216-049-91	KEO-CHIP	1K	5%	1/10W						
D 40-	4 040 0 15 5 :	DE0 01115	417	F0/	4/40111						
R425	1-216-049-91		1K	5%	1/10W						
R426	1-216-105-91	RES-CHIP	220K	5%	1/10W		<capacitor< td=""><td>&lt;&gt;</td><td></td><td></td><td></td></capacitor<>	<>			
R427	1-216-049-91	RES-CHIP	1K	5%	1/10W						
R428	1-216-025-91	RES-CHIP	100	5%	1/10W	C802	1-126-791-11	ELECT	10UF	20.00	% 16V
R430	1-216-025-91		100	5%	1/10W	C806	1-126-786-11		47UF		% 16V
	0 020 01			_ , 0			0 . 00 11			_0.00	
						1					



EF.NO.	PART NO.	DESCRIPTION	N	REMARK	REF.NO.	PART NO.	DESCRIPTION		REM	ARK
		CONNECTOR, PLUG, CONNE				<thermisto< td=""><td>OR&gt;</td><td></td><td></td><td></td></thermisto<>	OR>			
CINOUZ	1-304-303-11	PLUG, CONNE	CTOR 2P		TH801	1-807-796-11	THERMISTOR			
	<diode></diode>									
D801	8-719-059-93	DIODE SPR-50	5MVWT31 (P	OWER)	******	*******	*******	******	******	****
	<ferrite b<="" td=""><td>EAD&gt;</td><td></td><td></td><td>,</td><td>* 8-933-456-00</td><td>US BOARD, CO</td><td></td><td></td><td></td></ferrite>	EAD>			,	* 8-933-456-00	US BOARD, CO			
	1-216-295-91 1-216-295-91		0				******	*****		
FB803	1-216-295-91 1-216-295-91	SHORT	0			<capacitoi< td=""><td>₹&gt;</td><td></td><td></td><td></td></capacitoi<>	₹>			
	1-216-295-91		0			1-163-021-91 1-126-791-11	CERAMIC CHIP ELECT	0.01UF 10UF	10.00% 20.00%	50' 16'
	<chip cone<="" td=""><td>OUCTOR&gt;</td><td></td><td></td><td>C2604</td><td>1-126-791-11 1-126-791-11</td><td>ELECT</td><td>10UF 10UF</td><td>20.00% 20.00%</td><td>16\ 16\</td></chip>	OUCTOR>			C2604	1-126-791-11 1-126-791-11	ELECT	10UF 10UF	20.00% 20.00%	16\ 16\
JR1	1-216-295-91		0			1-126-791-11		10UF	20.00%	16
JR4	1-216-295-91	SHORT	0		C2607	1-126-176-11 1-126-176-11	ELECT	220UF 220UF	20.00%	10\ 10\
	<transisto< td=""><td>OR&gt;</td><td></td><td></td><td>C2609</td><td>1-126-176-11 1-126-176-11</td><td>ELECT</td><td>220UF 220UF</td><td>20.00%</td><td>10\ 10\</td></transisto<>	OR>			C2609	1-126-176-11 1-126-176-11	ELECT	220UF 220UF	20.00%	10\ 10\
		TRANSISTOR :				1-113-340-11		47UF	20.00%	25
Q803	8-729-027-31	TRANSISTOR: TRANSISTOR TRANSISTOR	DTA124EKA-	Γ146	C2901		CERAMIC CHIP		10.00% 10.00% 20.00%	50° 25° 25°
Q004	0-729-027-31	TRANSISTOR	DIAI24LNA-	1140	C2904	1-163-021-91	CERAMIC CHIP	0.01UF	10.00% 10.00%	50°
	<resistor:< td=""><td>&gt;</td><td></td><td></td><td></td><td></td><td>CERAMIC CHIP</td><td></td><td>10.00%</td><td>16</td></resistor:<>	>					CERAMIC CHIP		10.00%	16
	1-216-049-91 1-216-041-00			5% 1/10W 5% 1/10W	C2908	1-164-489-11	CERAMIC CHIP CERAMIC CHIP	0.22UF	10.00% 5.00%	16\ 50\
R803	1-216-033-00 1-216-033-00	RES-CHIP	220	5% 1/10W 5% 1/10W	C2912	1-163-235-11	CERAMIC CHIP	22PF	5.00% 10.00%	50\ 16\
	1-216-073-00			5% 1/10W			CERAMIC CHIP		10.00%	16\
	1-216-073-00 1-216-081-00			5% 1/10W 5% 1/10W			CERAMIC CHIP CERAMIC CHIP		10.00% 10.00%	25\ 25\
	1-216-097-91 1-216-675-91	RES-CHIP METAL CHIP		5% 1/10W 0.50%1/10W			CERAMIC CHIP		10.00% 10.00%	25 <sup>1</sup>
R821	1-215-401-11	METAL	150	1% 1/4W						
R822 R823	1-215-413-00 1-216-651-11	METAL METAL CHIP		1% 1/4W 0.50%1/10W		<connecto< td=""><td>OR&gt;</td><td></td><td></td><td></td></connecto<>	OR>			
	1-216-655-11 1-216-041-00	METAL CHIP RES-CHIP		0.50%1/10W 5% 1/10W			11 PIN, CONNECTOR	,	BOARD) 5	Р
R852	1-216-025-91	RES-CHIP	100	5% 1/10W			11 CONNECTOR 11 CONNECTOR	. ,		
R853	1-216-025-91	RES-CHIP	100	5% 1/10W	CN290	4 1-779-676-	11 CONNECTOR	R, USB (A)		
	<switch></switch>				CN290	5 1-779-676-	11 CONNECTOR	R, USB (A)		
S801		SWITCH, TACT	,	,		<diode></diode>				
	1-571-760-11	SWITCH, SLID SWITCH, KEYE SWITCH, KEYE	BOARD (RESÍ	ET)	D2604 D2605 D2606	8-719-911-19 8-719-911-19 8-719-911-19	ZENER DIODE   DIODE 1SS119- DIODE 1SS119- DIODE 1SS119- DIODE 1SS119-	25 25 25		
					D2903	8-719-422-12	ZENER DIODE I ZENER DIODE I ZENER DIODE I	MA8039		



REF.NO.	PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION	I	F	REMARK
		ZENER DIODE				<resistor></resistor>	•			
D2907	8-719-158-15	ZENER DIODE	RD5.6S-B		R2601	1-216-081-00	RES-CHIP	22K	5%	1/10W
		ZENER DIODE					METAL OXIDE		5%	1W
		ZENER DIODE			1		METAL OXIDE		5%	1W
		ZENER DIODE			1		METAL OXIDE		5%	1W
D2911	8-719-422-12	ZENER DIODE	MA8039		R2605	1-216-347-11	METAL OXIDE	0.68	5%	1W
D2912	8-719-422-12	ZENER DIODE	MA8039		R2607	1-216-349-00	METAL OXIDE	1	5%	1W
D2913	8-719-422-12	ZENER DIODE	MA8039		R2608	1-216-347-11	METAL OXIDE	0.68	5%	1W
D2914	8-719-422-12	ZENER DIODE	MA8039		R2609	1-216-349-00	METAL OXIDE	1	5%	1W
D2915	8-719-422-12	ZENER DIODE	MA8039		R2610	1-216-347-11	METAL OXIDE	0.68	5%	1W
					R2611	1-216-049-91	RES-CHIP	1K	5%	1/10W
	<ferrite bi<="" td=""><td>EAD&gt;</td><td></td><td></td><td>R2612</td><td>1-216-049-91</td><td>RES-CHIP</td><td>1K</td><td>5%</td><td>1/10W</td></ferrite>	EAD>			R2612	1-216-049-91	RES-CHIP	1K	5%	1/10W
					1	1-216-049-91		1K	5%	1/10W
FB2601		1-412-911-11	FERRITE	1.1UH	1	1-216-049-91		1K	5%	1/10W
FB2602		1-412-911-11	FERRITE		1	1-216-073-00		10K	5%	1/10W
FB2901		1-412-911-11	FERRITE			1-216-073-00		10K	5%	1/10W
FB2903	3	1-412-911-11	<b>FERRITE</b>	1.1UH						
FB2904	1	1-412-911-11	<b>FERRITE</b>	1.1UH	R2620	1-216-073-00	RES-CHIP	10K	5%	1/10W
					R2621	1-216-073-00	RES-CHIP	10K	5%	1/10W
FB2905	5	1-412-911-11	FERRITE	1.1UH	R2622	1-216-033-00	RES-CHIP	220	5%	1/10W
FB2906	5	1-412-911-11	FERRITE	1.1UH	R2901	1-216-013-00	RES-CHIP	33	5%	1/10W
FB2911		1-412-911-11	FERRITE	1.1UH	R2902	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
FB2912		1-216-295-91	SHORT	0						
FB2913	3	1-216-295-91	SHORT	0	1	1-216-121-91		1M	5%	1/10W
	_			_	1	1-216-065-91		4.7K	5%	1/10W
FB2914		1-216-295-91	SHORT	0	1	1-216-073-00		10K	5%	1/10W
FB2915		1-216-295-91	SHORT	0		1-216-022-00		75	5%	1/10W
FB2916		1-216-295-91	SHORT	0	R2907	1-216-039-00	RES-CHIP	390	5%	1/10W
FB2917		1-216-295-91	SHORT	0	Danne	1 246 072 00	DEC CLUD	101/	E0/	4/40\\\
FB2918	)	1-216-295-91	SHORT	U		1-216-073-00 1-216-065-91		10K 4.7K	5% 5%	1/10W 1/10W
FB2919	3	1-216-295-91	SHORT	0		1-216-053-00		4.7K 1.5K	5% 5%	1/10W
FB2924		1-216-295-91	SHORT	0	1	1-216-033-00		1.5K	5%	1/10W
FB2925		1-216-295-91	SHORT	0		1-216-077-91		15K	5%	1/10W
FB2936		1-414-766-22	INDUCTOR		112313	1210011-31	NEO OF III	1010	370	1/1000
					R2920	1-216-077-91	RES-CHIP	15K	5%	1/10W
					1	1-216-077-91		15K	5%	1/10W
	<ic></ic>					1-216-077-91		15K	5%	1/10W
		10.000				1-216-077-91		15K	5%	1/10W
	8-759-431-14 8-759-639-01	IC PQ3TZ53U IC SDI02-V1			R2926	1-216-077-91	RES-CHIP	15K	5%	1/10W
	8-759-639-01				R2927	1-216-013-00	RES-CHIP	33	5%	1/10W
		IC KC82C160SH	1		1	1-216-013-00		33	5%	1/10W
		IC PST600J-T				1-216-009-91		22	5%	1/10W
					1	1-216-009-91		22	5%	1/10W
	<b></b>				R2932	1-216-077-91	RES-CHIP	15K	5%	1/10W
	<transisto< td=""><td>JK&gt;</td><td></td><td></td><td>B2033</td><td>1-216-013-00</td><td>RES-CHIP</td><td>33</td><td>5%</td><td>1/10W</td></transisto<>	JK>			B2033	1-216-013-00	RES-CHIP	33	5%	1/10W
Q2601	8-729-029-06	TRANSISTOR D	TC124F114	-T106		1-216-013-00		33	5%	1/10W
		TRANSISTOR D			1	1-216-013-00		33	5%	1/10W
		TRANSISTOR D			1	1-216-013-00		33	5%	1/10W
		TRANSISTOR D				1-216-013-00		33	5%	1/10W
						<crystal></crystal>				
					X2901	1-767-925-21	VIBRATOR, CR	YSTAL (1	2MHz)	
							•		,	